


Operating instructions

Metering pumps

Hydro/ 2 and Hydro/ 3

EN

Please carefully read these operating instructions before use. · Do not discard.
The operator shall be liable for any damage caused by installation or operating errors.
The latest version of the operating instructions are available on our homepage.

Supplementary information



Fig. 1: Please read!

Read the following supplementary information in its entirety! Should you already know this information, you will benefit more from referring to the operating instructions.

The following are highlighted separately in the document:

- Enumerated lists

- ➔ Operating guidelines

- ⇒ Outcome of the operating guidelines

- see (reference)

Information



This provides important information relating to the correct operation of the unit or is intended to make your work easier.

Safety Information

Safety information is identified by pictograms - see Safety Chapter.

Information in supplier instructions

Refer to the precise designation of suppliers' components in the "Technical Data" chapter for ease of finding the relevant information.

Validity

These operating instructions conform to current EU regulations applicable at the time of publication.

State the identity code and serial number

Please state identity code and serial number, which you can find on the nameplate when you contact us or order spare parts. This enables the unit type and material versions to be clearly identified.

EX pumps only

The nameplate stuck on the cover page is identical to the pump supplied so that there is a clear link between the operating instructions and the pump.

Table of contents

1	Identity code	5
2	Safety chapter	10
	2.1 Safety information for ATEX designs.....	15
	2.2 Explanation of the ATEX label.....	26
3	Storage, transport and unpacking	29
4	Overview of equipment / control elements	31
5	Functional description	32
6	Assembly	33
7	Installation	37
	7.1 Installation, hydraulic.....	37
	7.1.1 Basic installation notes.....	40
	7.2 Installation, electrical.....	42
8	Start up and operation	48
	8.1 Bleeding the liquid end.....	51
	8.2 Calibrate the stroke control drive (optional).....	52
9	Maintenance	53
10	Repair	59
	10.1 Cleaning valves.....	60
	10.2 Replacing the diaphragm.....	62
	10.3 Repairing the diaphragm rupture sensor.....	64
	10.4 Calibrating the dosing rate.....	66
	10.5 Replacing power end bearings.....	68
11	Troubleshooting	69
12	Decommissioning and disposal	73
	12.1 Decommissioning.....	73
	12.2 Disposal.....	74
13	Technical data	76
	13.1 Performance data.....	77
	13.2 Metering reproducibility.....	80
	13.3 Viscosity.....	81
	13.4 Weight.....	81
	13.5 Wetted materials.....	81
	13.6 Ambient conditions.....	82
	13.6.1 Temperatures.....	82
	13.6.2 Air humidity.....	83
	13.6.3 Installation height.....	83
	13.7 Housing degree of protection.....	83
	13.8 Motor data.....	83
	13.9 Diaphragm rupture sensor.....	85
	13.10 Safety relief valve (HP2 and HP3).....	86
	13.11 Stroke sensor.....	86
	13.12 Heating cartridge.....	86
	13.13 Protection temperature limiter (ATEX only).....	87
	13.14 Filling volumes.....	87
	13.14.1 Hydraulic oil.....	87
	13.15 Sound pressure level HP2a / Hp3a.....	87
	13.16 Supplement for modified versions.....	87
14	Dimensional drawings	89
15	Earthing drawing	102
16	Diagrams for setting the metering capacity	103

17	Ordering information.....	105
17.1	Exploded view drawing.....	105
17.2	Spare parts kits.....	105
17.3	Diaphragms.....	107
17.4	General.....	107
18	EU Declaration of Incorporation for Machines HP2.....	109
19	EU Declaration of Incorporation for Machines HP3.....	110
20	EC Declaration of Conformity for HP2 Machines.....	111
21	EC Declaration of Conformity for HP3 Machines.....	112
22	EC Declaration of Incorporation for ATEX HP2 Machines.....	113
23	EC Declaration of Incorporation for ATEX HP3 Machines.....	114
24	EC Declaration of Conformity for ATEX HP2 Machines.....	115
25	EC Declaration of Conformity for ATEX HP3 Machines.....	116

1 Identity code

HP2a	Hydro/ 2, version a
	Power end type
H	Main power end
D	Main power end, double head version
E	Main power end for add-on power end
F	Main power end double head version for add-on power end
A	Add-on power end
B	Add-on power end double head version
Typ e *	Capacity
---	Performance data at maximum back pressure and type: refer to nameplate on the pump housing

	Dosing head material
SS	Stainless steel
PV	PVDF
HC	Hastelloy C
TT	PTFE + carbon
	Seal material
T	PTFE
	Displacement body
0	Standard multi-layer safety diaphragm with rupture signalling
	Dosing head design
0	no valve spring (standard)
1	with valve spring
D	Double ball valve (only for SST and HCT)
H	HV version for (only for 025019 ... 025060)
	Hydraulic connector
0	Standard threaded connector (in line with technical data)
E	with DIN ISO flange
F	with ANSI flange
	Design
0	with ProMinent® logo (standard)
1	without ProMinent® logo
M	modified* * order-related design, refer to order paperwork for pump features
	Electric power supply
S	3-phase, 230 V/400 V 50/60 Hz, 0.37 kW
L	3-phase, 230 V/400 V, 50 Hz, (Exe, Exde), 0.37 kW
P	3-phase, 265 V/440 V, 60 Hz, (Exe, Exde), 0.37 kW
R	3-phase variable speed stroke control motor, 230/400 V, 0.37 kW

HP2a	Hydro/ 2, version a								
								V(0)	Variable stroke control motor with integrated frequency converter 1-phase, 230 V, 50/60 Hz
								V(2)	Variable stroke control motor with integrated frequency converter (Exd)
								Z	Speed control complete 1-phase, 230 V, 50/60 Hz (stroke control motor + frequency converter)
								1	without motor, with flange 200/80
								3	without motor, with flange 160/71
								4	without motor, with 56C flange (NEMA)
								0	Add-on power end
								Degree of protection	
								0	IP 55 (standard) ISO class F
								1	Exe design ATEX-T3 **
								2	Exde design ATEX-T4 **
								A	ATEX power end **
								Stroke sensor	
								0	no stroke sensor (standard)
								1	Stroke sensor (suitable for use in areas at risk from explosion)
								Stroke length adjustment	
								0	manual (standard)
								1	with servomotor, 230 V, 50/60 Hz
								2	with servomotor, 115 V, 60 Hz
								A	with stroke control motor 0...20 mA 230 V, 50/60 Hz
								B	with stroke control motor 4...20 mA 230 V, 50/60 Hz
								C	with stroke control motor 0...20 mA 115 V, 60 Hz
								D	with stroke control motor 4...20 mA 115 V, 60 Hz
								Hydraulic oil	
								0	Standard
								1	Food approval for oil
								2	Low temperature to -25 °C
								3	Low temperature Zone 2


Tab. 1: * Type, power (at 50 Hz)

Type	Capacity		Type	Capacity		Type	Capacity	
	bar	l/h		bar	l/h		bar	l/h
100003	100 ¹	3	064007	64 ¹	7	025019	25 ¹	19
100006	100 ¹	6	064015	64 ¹	15	025040	25 ¹	40
100007	100 ¹	7	064018	64 ¹	18	025048	25 ¹	48

Type	Capacity		Type	Capacity		Type	Capacity	
	bar	l/h		bar	l/h		bar	l/h
100009	100 ¹	9	064022	64 ¹	22	025060	25 ¹	60
100010	100 ¹	10	064025	64 ¹	25	025068	25 ¹	68

¹ Maximum back pressure for TTT material version: 16 bar!

Maximum back pressure for PVT material version: 25 bar!

** ATEX specification - refer to the nameplate on the pump, corresponding EU Declaration of Conformity for ATEX Machinery and  Chapter 2.2 'Explanation of the ATEX label' on page 26

HP3a	Hydro/ 3, version a	
	Power end type	
H	Main power end	
D	Main power end, double head version	
E	Main power end for add-on power end	
F	Main power end double head version for add-on power end	
A	Add-on power end	
B	Add-on power end double head version	
	Type	Capacity
	----- _	Performance data at maximum back pressure and type: refer to the nameplate on the pump
	Dosing head material	
	SS	Stainless steel
	PV	PVDF
	H C	Hastelloy C
	TT	PTFE + carbon
	Seal material	
	T	PTFE
	Displacement body	
	0	Standard multi-layer safety diaphragm with rupture signalling
	Dosing head design	
	0	no valve spring (standard)
	1	with valve spring
	D	Double ball valve (for 100010 ... 100035, 064019 ... 064060 and SST / HTC)
	H	HV version (for 064019 ... 064068, 025048 ... 025170)
	Hydraulic connector	
	0	Standard threaded connector (in line with technical data)
	E	with DIN ISO flange
	F	with ANSI flange
	Design	
	0	with ProMinent® logo (standard)
	1	without ProMinent® logo
	M	modified* * order-related design, refer to order paperwork for pump features
	Electric power supply	
	_	Connection data - see motor nameplate
	1	without motor, with flange 200/80
	3	without motor, with flange 160/71
	4	without motor, with 56C flange (NEMA)
	0	Add-on power end
	Degree of protection	

HP3a	Hydro/ 3, version a								
								0	IP 55 (standard) ISO class F
								1	Exe design ATEX-T3 **
								2	Exde design ATEX-T4 **
								A	ATEX power end
								Stroke sensor	
								0	no stroke sensor (standard)
								1	Stroke sensor (suitable for use in areas at risk from explosion)
								Stroke length adjustment	
								0	manual (standard)
								1	with servomotor, 230 V, 50/60 Hz
								2	with servomotor, 115 V, 60 Hz
								A	with stroke control motor 0...20 mA 230 V, 50/60 Hz
								B	with stroke control motor 4...20 mA 230 V, 50/60 Hz
								C	with stroke control motor 0...20 mA 115 V, 60 Hz
								D	with stroke control motor 4...20 mA 115 V, 60 Hz
								Hydraulic oil	
								0	Standard
								1	Food approval for oil
								2	Low temperature to -25 °C
								3	Low temperature Zone 2

Tab. 2: * Type, power (at 50 Hz)

Type	Capacity		Type	Capacity		Type	Capacity	
	bar	l/h		bar	l/h		bar	l/h
100010	100 ¹	10	064019	64 ¹	19	025048	25 ¹	48
100021	100 ¹	21	064040	64 ¹	40	025100	25 ¹	100
100025	100 ¹	25	064048	64 ¹	48	025120	25 ¹	120
100031	100 ¹	31	064060	64 ¹	60	025150	25 ¹	150
100035	100 ¹	35	064068	64 ¹	68	025170	25 ¹	170

¹ Maximum back pressure for TTT material version: 16 bar!

Maximum back pressure for PVT material version: 25 bar!

** ATEX specification - refer to the nameplate on the pump, corresponding EU Declaration of Conformity for ATEX Machinery and [Chapter 2.2 'Explanation of the ATEX label'](#) on page 26

2 Safety chapter






Explanation of the safety information

The following signal words are used in these operating instructions to identify different severities of a hazard:

Signal word	Meaning
WARNING	Denotes a possibly hazardous situation. If this is disregarded, you are in a life-threatening situation and this can result in serious injuries.
CAUTION	Denotes a possibly hazardous situation. If this is disregarded, it could result in slight or minor injuries or material damage.

Warning signs denoting different types of danger

The following warning signs are used in these operating instructions to denote different types of danger:

Warning signs	Type of danger
	Warning – hand injuries.
	Warning – high-voltage.
	Warning – flammable substances.
	Warning – hot surface.
	Warning – danger zone.

Intended use

- Only use the pump to meter liquid feed chemicals.
- The pump is only approved for use with flammable feed chemicals if it has the identity code option "Standard multi-layer safety diaphragm with rupture signalling", is operated at back pressures of over 2 bar with metal liquid ends and if the operator implements appropriate safety measures.
- The pump may only be started up after it has been correctly installed and started up in accordance with the technical data and specifications contained in the operating instructions. When working at temperatures arising using a heating cartridge, bear in mind their effect.
- Observe the general limitations with regard to viscosity limits, chemical resistance and density - see also the ProMinent Resistance List (in the Product Catalogue or at www.prominent.com)!
- All other uses or modifications are prohibited.
- The pump is not intended for the metering of gaseous media and solids.
- The pump is not intended for the metering of explosive substances and explosive mixtures.
- The pump is not intended for unprotected use outdoors.
- The pump is only intended for industrial use.
- Only allow trained and authorised personnel to operate the pump - see the following table.

- You have a responsibility to adhere to the information contained in the operating instructions at the different phases of the unit's service life.
- You have a responsibility to observe the information contained in the operating instructions for the auxiliary equipment at the different phases of their respective service lives.

Qualification of personnel

Task	Qualification
Storage, transport, unpacking	Instructed person
Assembly	Technical personnel, service
Planning the hydraulic installation	Qualified personnel who have a thorough knowledge of oscillating metering pumps
Hydraulic installation	Technical personnel, service
Electrical installation	electrical technician,
Start up	Technical personnel
Operation	Instructed person
Maintenance, repair	Technical personnel, service
Decommissioning, disposal	Technical personnel, service
Troubleshooting	Qualified person, electrical technician, instructed person, service - depending on the requirement

Explanation of the table:

Trained, qualified personnel

A trained, qualified employee is deemed to be a person who is able to assess the tasks assigned to him and recognise possible hazards based on his training, knowledge and experience, as well as knowledge of pertinent regulations. A trained, qualified employee must be able to perform the tasks assigned to him/her independently with the assistance of drawing documentation and parts lists. The assessment of a person's technical training can also be based on several years of work in the relevant field.

Electrical technician

An electrical technician is able to complete work on electrical systems and recognise and avoid possible dangers independently based on his technical training and experience as well as knowledge of pertinent standards and regulations. An electrical technician must be able to perform the tasks assigned to him/her independently with the assistance of drawing documentation, parts lists, terminal and circuit diagrams. The electrical technician must be specifically trained for the working environment in which the electrical technician is employed and be conversant with the relevant standards and regulations.

Electrical technician with knowledge of ATEX explosion protection

An electrical technician with an additional explosion protection qualification should be specifically trained for the field of work in which he is employed and be familiar with the relevant standards and regulations. An electrical technician with an additional explosion protection qualification can work on electrical systems and independently recognise and avoid possible dangers based on his technical training and experience.

The electrical technician with an additional explosion protection qualification is familiar with all the standards and regulations applicable to explosion protection, in particular, but not however exclusively, with all parts of EN 60079 [Electrical equipment for areas at risk of a gas explosion].

An electrical technician with an additional explosion protection qualification must comply with the provisions of the applicable statutory directives on accident prevention.

Recognised competent person

To carry out explosion hazard inspections the competent person must have:

- Completed a relevant course of study or
- Have a comparable technical qualification or
- Another technical qualification combined with long-term experience of safety technology.

Make sure that the person is familiar with the relevant body of standards and regulations and has worked in the field for at least one year. The person needs to have opportunities for an exchange of experiences.

Specific requirements are placed on competent persons who perform tests on repaired devices/parts. They must be **recognised** by the responsible authorities (e.g. district council) in this respect.

Instructed person

An instructed person is deemed to be a person who has been instructed and, if required, trained in the tasks assigned to him/her and possible dangers that could result from improper behaviour, as well as having been instructed in the required protective equipment and protective measures.

Trained user

A trained user is a person who fulfils the requirements demanded of an instructed person and who has also received additional training specific to the system from ProMinent or another authorised distribution partner.

Service

Service refers to service technicians, who have received proven training and have been authorised by ProMinent to work on the system.

Safety information



CAUTION!

These operating instructions include notes and extracts from German regulations relating to the operator's scope of responsibility. This information does not discharge the operator from his responsibility as an operator and is intended only to remind him or make him aware of specific problem areas. This information does not lay claim to being complete, nor applicable to every country and every type of application, nor to being unconditionally up-to-date.



WARNING!

Warning of hazardous feed chemical

Should a dangerous feed chemical be used: it may escape from the hydraulic components when working on the pump, material failure or incorrect handling of the pump.

- Take appropriate protective measures before working on the pump (e.g. safety glasses, safety gloves, ...). Adhere to the material safety data sheet for the feed chemical.
- Drain and flush the liquid end before working on the pump.

**WARNING!****Danger from hazardous substances!**

Possible consequence: Fatal or very serious injuries.

Please ensure when handling hazardous substances that you have read the latest safety data sheets provided by the manufacture of the hazardous substance. The actions required are described in the safety data sheet. Check the safety data sheet regularly and replace, if necessary, as the hazard potential of a substance can be re-evaluated at any time based on new findings.

The system operator is responsible for ensuring that these safety data sheets are available and that they are kept up to date, as well as for producing an associated hazard assessment for the workstations affected.

**CAUTION!****Warning of feed chemical spraying around**

Feed chemical can spray out of the hydraulic components if they are manipulated or opened due to pressure in the liquid end and adjacent parts of the system.

- Disconnect the pump from the mains power supply and ensure that it cannot be switched on again by unauthorised persons.
- Depressurise the system before commencing any work on hydraulic parts.

**CAUTION!****Warning of feed chemical spraying around**

An unsuitable feed chemical can damage the parts of the pump that come into contact with the chemical.

- Take into account the resistance of the wetted materials and the ProMinent Resistance List when selecting the feed chemical - see the ProMinent Product Catalogue or visit ProMinent.

**WARNING!****Danger of injury to personnel and material damage**

The pump must only be opened at those points required to be opened by these operating instructions.

It may only be opened in other positions upon receipt of written authorisation from the ProMinent head office, Heidelberg.

**CAUTION!****Danger of personnel injury and material damage**

The use of untested third party parts can result in personnel injuries and material damage.

- Only fit parts to metering pumps, which have been tested and recommended by ProMinent.



CAUTION!

Danger from incorrectly operated or inadequately maintained pumps

Danger can arise from a poorly accessible pump due to incorrect operation and poor maintenance.

- Ensure that the pump is accessible at all times.
- Adhere to the maintenance intervals.

Information in the event of an emergency

In the event of an electrical accident, disconnect the mains cable from the mains or press the emergency cut-off switch fitted on the side of the system!

If feed chemical escapes, also depressurise the hydraulic system around the pump as necessary. Adhere to the safety data sheet for the feed chemical.

Safety information for operating instructions

Prior to commissioning the system or system component, it is the responsibility of the system operator to obtain the latest safety data sheet for the chemicals / equipment to be used with the system from the supplier. Based on the information provided in the data sheets concerning health and safety, water and environmental protection, and taking into consideration the actual operating environment on site, it is the responsibility of the operator to create the legal framework for the safe operation of the system or system component, such as for example the preparation of operating instructions (operator's duties).

Safety equipment

Fixed, isolating protective equipment

Secure all these parts in their place when using the pump.

Protective equipment	May only be removed by*:
Motor terminal box cover	Electrical technician, Service
Flange cover, side	Service
Protective cowling over the motor fan	Service
Only with additional equipment: Their corresponding parts	Technical personnel, Service

* Only if required by the operating instructions and if the mains cable remains disconnected from the mains voltage.

Requirements if the motor is being installed independently

The operator must be able to:

- Perform a risk assessment
- Produce and attach a nameplate
- Issue a Declaration of Conformity
- Adapt the operating instructions, if necessary
- Install the motor correctly

Sound pressure level

Sound pressure level LpA < 70 dB according to EN ISO 20361 at maximum stroke length, maximum stroke rate, maximum back pressure (water)

2.1 Safety information for ATEX designs

This chapter lists all safety information for ATEX designs. Safety information is listed again at the relevant points in these operating instructions.

This safety information is supplementary to or replaces the safety information for non-ATEX designs. If the safety information for ATEX designs contradicts the other safety information, then the safety information in this chapter applies to ATEX designs.

Intended use

- Only operate the pump in premises at risk from explosion in an ATEX designs in accordance with the applicable guidelines.
- Do not expose the ATEX design to any sources of ionising radiation or electromagnetic high frequency radiation in the range $10^4 \dots 3 \times 10^{15}$ Hz or laser radiation or ultrasound or lightning without putting in place measures in line with EN 80079-38.
- The ATEX design is not intended for the metering of electrically non-conductive media (conductivity less than 50 pS/m).
- The ATEX design may not meter media, which tend to produce exothermic reactions or self-ignite (examples of exothermic reactions: pyrophoric substances with air, alkali metal with water, decomposition of organic peroxides, polymerisation reactions), without taking effective measures in accordance with EN 80079-38.

Qualification of personnel

Task	Qualification
Planning the hydraulic installation	ATEX qualified person, ATEX electrical technician
Electrical installation	ATEX electrical technician
Start up	Skilled ATEX technician; Checking the electrical installation: Recognised competent person
Maintenance, repair	ATEX qualified person, ATEX electrical technician
Troubleshooting	Qualified ATEX technician or ATEX electrical technician - depending on the fault; Checking the electrical installation: Recognised competent person

Explanation of the table:

Recognised competent person

To carry out explosion hazard inspections the competent person must have:

- Completed a relevant course of study or
- Have a comparable technical qualification or
- Another technical qualification combined with long-term experience of safety technology.

Make sure that the person is familiar with the relevant body of standards and regulations and has worked in the field for at least one year. The person needs to have opportunities for an exchange of experiences.

Specific requirements are placed on competent persons who perform tests on repaired devices/parts. They have to be **recognised** by the responsible authorities (e.g. district council) in this respect.

Skilled technician with knowledge of ATEX explosion protection

The skilled technician with an additional explosion protection qualification should be specifically trained for the work area in which he is employed and be familiar with the relevant standards and regulations. The skilled technician with an additional explosion protection qualification can work on equipment and systems in areas protected from explosion and independently recognise and avoid possible dangers based on his technical training and experience.

The skilled technician with an additional explosion protection qualification is familiar with all the standards and regulations applicable to explosion protection.

The skilled technician with an additional explosion protection qualification must comply with the provisions of the applicable statutory directives on accident prevention.

Electrical technician with knowledge of ATEX explosion protection

An electrical technician with an additional explosion protection qualification should be specifically trained for the field of work in which he is employed and be familiar with the relevant standards and regulations. An electrical technician with an additional explosion protection qualification can work on electrical systems and independently recognise and avoid possible dangers based on his technical training and experience.

The electrical technician with an additional explosion protection qualification is familiar with all the standards and regulations applicable to explosion protection.

An electrical technician with an additional explosion protection qualification must comply with the provisions of the applicable statutory directives on accident prevention.

Recognised competent person

To carry out explosion hazard inspections the competent person must have:

- Completed a relevant course of study or
- Have a comparable technical qualification or
- Another technical qualification combined with long-term experience of safety technology.

Make sure that the person is familiar with the relevant body of standards and regulations and has worked in the field for at least one year. The person needs to have opportunities for an exchange of experiences.

Specific requirements are placed on competent persons who perform tests on repaired devices/parts. They must be recognised by the responsible authorities (e.g. district council) in this respect.

Summary of relevant ignition hazards and protective measures put in place for the Hydro in accordance with EN ISO 80079-36

Ignition hazard	Protective measures to be observed by the customer
Excessive surface pressure	Limitation of the maximum temperature of the feed chemical
Pump running hot	Customer must monitor and maintain the pump in accordance with the "Maintenance" chapter. Customer must monitor the capacity. Customer must fit a relief valve on the discharge side.
Mechanically generated sparks from the mechanism with low oil	Customer must monitor and maintain the pump in accordance with the "Maintenance" chapter.
Mechanically generated sparks from a faulty valve for the feed chemical	Customer must monitor the capacity.
Electrical stray current in the event of a short circuit	Customer must earth the pump and maintain the earthing of the individual components.

Ignition hazard	Protective measures to be observed by the customer
Electrical stray current in the event of a lightning strike	Customer must implement suitable protective measures outdoors.
Static electricity	<p>Customer must earth the earthing points and maintain the potential equalisation cables of the individual components.</p> <p>Customer must pay attention to potential equalisation when dismantling.</p> <p>Paint should not be applied too thickly.</p> <p>Only with plastic dosing heads: Only use feed chemicals with conductivities above 50 pS/m.</p> <p>Customer must wire the diaphragm rupture indicator in such a way that it immediately stops the pump.</p>
Electromagnetic waves (also lasers), ionising radiation and ultra-sound have an impact on the pump	The customer must put in place measures in accordance with EN 1127-1, if need be.
Adiabatic compression and shock waves	Flammable feed chemicals: Do not allow the unit to run dry – even when filling and emptying the liquid end.
Exothermic reaction, including the self-combustion of dust	<p>The pump is not suitable for use with substances that have a tendency towards exothermic reactions or self-combustion. Put in place measures in accordance with EN 1127-1, if need be.</p> <p>Feed chemicals that undergo an exothermic reaction with hydraulic oil: Customer must wire the diaphragm rupture indicator in such a way that it immediately stops the pump.</p>
Deposits of dust	Regularly clean the outside of the pump with a damp cloth.
Flammable feed chemicals	Customer must wire the diaphragm rupture indicator in such a way that it immediately stops the pump.
Ignition hazard with bought-in motor components	<p>Refer to the documentation for the motor.</p> <p>Comply with the monitoring intervals.</p> <p>The insulation resistance needs to be greater than 5 MOhm.</p> <p>Provide a time-delay residual current device.</p> <p>Provide overload protection by a motor protection switch or an equivalent protective device.</p> <p>Observe the minimum spacing between the air inlet on the fan hood and any obstacles.</p> <p>Avoid deposits of dust more than 5 mm deep.</p> <p>Connect the earth wire.</p> <p>Max. installation height: 1,000 m.a.s.l.</p>
Ignition hazard with bought-in actuator or control drive components	<p>Refer to the documentation for the actuator.</p> <p>Wait 3 minutes after switching off before opening the housing.</p>
Ignition hazard with bought-in Rotex coupling	Refer to the documentation for the coupling (maintenance, alignment if necessary, ...).
Ignition hazard caused by bought-in heating cartridge with protective temperature limiter	<p>Refer to the documentation for the heating cartridge and the protective temperature limiter (electrical installation, maintenance, ...).</p> <p>Do not reprogram the protective temperature limiter.</p>
Ignition hazard caused by bought-in proximity switch NJ1.5-8GM-N (stroke sensor, diaphragm rupture indicator)	Refer to the documentation for the proximity switch (electrical installation, maintenance, ...).

Safety information



WARNING!

Only use ATEX pumps in areas at risk from explosion

- Observe the European Operator Directive, implemented in Germany by the Industrial Health and Safety Regulation, and the German Ordinance on Hazardous Substances, for the installation and operation of equipment in areas at risk from explosion.
- Observe the European standards governing intrinsically safe power circuits. (In Germany these standards are partly implemented by VDE.)
- Adhere to the respective national regulations outside of the EU.
- Ensure that installations in areas at risk of explosion are checked by a "recognised competent" person. This applies specifically to intrinsically safe power circuits.
- The following information relates essentially to specifics in areas at risk from explosion and does not replace the standard operating instructions.
- Only clean plastic parts carefully with a damp cloth to avoid electrostatic charges and sparks.



WARNING!

Motor may overheat

If the necessary cooling air supply is not guaranteed, the motor may overheat. In an area at risk from explosion, it could trigger an explosion.

- Maintain sufficient clearance between the air intake opening and the walls. The distance should be greater than 1/4 of the diameter of the air intake opening.
- The fan must not suck in the exhaust air from other devices.



WARNING!

ATEX pumps in areas at risk from explosion

- Metering pumps in areas at risk of explosion are provided, as a matter of course, with an appropriate safety relief valve on the outlet side of the metering pump (which is used to protect against excessive heating due to overloading and impact sparks caused by the breakage of power end parts triggered by overloading.)
- Likewise a temperature monitor or a pressure side flow control is to be fitting to metering pumps with hydraulic diaphragm control for T4. (Protection against impermissible heating up in the event of continuous operation by the internal relief valve).
- Should the various components have differing temperature classes, scope for using the complete pump depends on the component with the lowest temperature class.
- Hydraulic diaphragm pumps are highly suitable, although the design with Ex "i" diaphragm rupture sensor and a pressure-side flow control is required.
- Ensure that installations in areas at risk of explosion are checked by a "recognised competent" person.
- Please note the relevant national regulations during installation!

**WARNING!****ATEX pumps and flammable media**

The ignition temperature is reduced significantly below the ignition temperature at atmospheric pressure due to compression with the discharge stroke of the possibly ignitable vapour-air mixture.

- Do not allow it to run dry. Take appropriate protective measures.
- Immediately switch off the pump in the event of a diaphragm rupture.

**WARNING!****Risk of fire with flammable feed chemicals**

- Combustible media may only be transported using stainless steel or Hastelloy C dosing heads.
- Metering pumps can be used for metering combustible media, however as a matter of principle only of a design including ATEX diaphragm rupture sensors and a pressure-side flow control.
- During filling and draining of the liquid end, an expert must ensure that feed chemical does not come into contact with air.
- If necessary, the operator must implement further measures.

**WARNING!****ATEX pumps in areas at risk from explosion**

- Make sure that a suitably competent person checks whether the appropriate installation information from the "Installation " chapter has been implemented correctly.
- Make sure that a "recognised competent person" checks the electrical installation and in particular the intrinsically safe power circuits.
- Set the opening pressure of the relief valve at a maximum of no more than 1.5 times the rated pressure of the pump.

**WARNING!****ATEX pumps in areas at risk from explosion**

If feed chemicals are metered, which tend to produce exothermic reactions or self-ignite (examples of exothermic reactions: pyrophoric substances with air, alkali metal with water, decomposition of organic peroxides, polymerisation reactions), they can lead to high temperatures and ignition.

- Put in place measures in accordance with EN 80079-38.

**WARNING!****ATEX pumps in areas at risk from explosion**

If abrasive media are being metered, they will escape as soon as all layers of the diaphragm have eroded through.

- Wire the electrical diaphragm rupture indicator to stop the pump in the event of a diaphragm rupture.



WARNING!

ATEX pumps in areas at risk from explosion

- Electrically wire all electrical units cleanly and permanently to an electrically clean earthing point, - e.g. with an earthing bar on your system.
- Electrically connect the electrical units fitted with a potential equalisation cable to each other, cleanly and permanently, to an electrically clean potential equalisation point - e.g. with a potential equalisation bar on your system.
- Note the enclosed documentation for the individual electrical components.



WARNING!

ATEX pumps in areas at risk from explosion

- Use a suitable motor protection switch to protect power end motors. Use motor protection approved for this application with Ex"e" motors. (Protection against warming caused by overloading)
- Provide a time-delay residual current device.
- Observe the enclosed operating instructions for the Ex motor.



WARNING!

The following applies in areas at risk from explosion:

- Note the details of the type examination certificate PTB 00 ATEX 2048 X for the Namur sensor NJ1.5-8GM-N as well.



WARNING!

ATEX pumps in areas at risk from explosion

- Make sure that a suitably competent person checks whether the appropriate installation information from the "Installation " chapter has been implemented correctly.
- Make sure that a "recognised competent person" checks the electrical installation and in particular the intrinsically safe power circuits.
- Set the opening pressure of the relief valve to a maximum of no more than 1.5 times the nominal pressure of the pump.

**WARNING!****ATEX pumps in areas at risk from explosion**

- Carry out a general check to ensure that the system is working properly, particularly the power end and bearings, by regularly monitoring it (for leaks, noises, temperatures, smell, etc.).
- Do not allow the pump to run hot due to a lack of oil. With lubricated metering pumps, regularly check for the presence of lubricant, for example by checking the liquid level, visual leak control etc. If oil is escaping, investigate the leak immediately and eliminate the cause.
- Check the correct operation of the relief valve downstream of the pump. In premises at risk from explosion, the relief valve should prevent the gear from becoming overloaded and becoming hot.
- Observe the enclosed operating instructions for the Ex motor.
- Only with pumps with a motor flange: Check / replace worn gear ring etc. of the clutch.
- Only with add-on power end: Check / replace worn gear ring/DZ element of the clutch.
- Check the seals of the pressure switch for leak-tightness.
- When cleaning plastic components, ensure that no electrostatic charges are generated by excessive friction.
- Always earth the discharge line and the suction line against the pump to prevent electrostatic charge before working on the pump.
- Have wear parts, such as bearings, replaced by ProMinent Service when there is an identifiable incidence of unacceptable wear.
- Check whether the potential equalisation lines are all sitting correctly with clean contacts.
- Check whether the earth lines are all sitting correctly with clean contacts. Use the earthing drawings as an aid – see Appendix.
- Only use genuine spare parts as replacements.
- Appropriate diagnostic equipment for bearing damage is recommended for the premature detection of bearing damage.
- Carry out inspections and repair in compliance with DIN EN IEC 60079-17, as an example, and ensure that they are only performed by "experienced personnel with the requisite knowledge".
- If re-painting, do not increase the layer thickness.
- These measures are deemed to be minimum protection measures by ProMinent. It is the duty of the operator to take appropriate measures to eliminate any further hazards known to him.

**WARNING!****ATEX pumps in areas at risk from explosion**

- Static electricity can cause ignition sparks.
- Consider potential equalisation before you approach any pump equipment that could be at a different electrical potential (such as pipes or tools)

Potential equalisation line (prescribed in the area at risk from explosion)

The entire installation supplied is provided ex works with the necessary potential equalisation lines.

Electrically wire an additional potential equalisation cable from the potential equalisation cables from this system cleanly and permanently to an electrically clean potential equalisation point, e.g. to a potential equalisation bar on site.

Potential equalisation of frame

An earthing point for the customer is fitted on the frame.

When a frame is used, a motor screw is factory-connected by a protective earth cable to the earthing point.

Namur sensor (Specified for EX zones)

5–25 V DC, in accordance with Namur or DIN 19234, potential-free design.

Data	Value	Unit
Rated voltage *	8	VDC
Power consumption - active surface uncovered	> 3	mA
Power consumption - active surface covered	< 1	mA
Rated switching distance	1.5	mm

* Ri ~ 1 kΩ

Cable colour	Polarity
blue	-
brown	+



Install the sensor according to the chapter "Installation, electrical". Refer to its documentation.

Sensor name: NJ1.5-8GM-N.

ATEX pressure switch



CAUTION!


Observe the accompanying manual "HYDAC Operating manual pressure switch series EDS 4400 with ATEX approval".

Tab. 3: Type identification

Type identification	Feature	Property
EDS 4	Designation of the pressure switch	EDS 4
4	Precision:	Thin film/relative pressure
4	Mechanical connection:	G ¼ A DIN 3852, external thread
8	Electrical connection:	Device plug, M12x1, 5-pole
0060	Measuring range:	specification in bar
P	Control output:	programmable

Type identification	Feature	Property
A	Certification:	ATEX
N	Electrical strength:	125 V AC relative to the housing
3	Degrees of protection:	II 2G Ex ia IIC T4
004	Modification number:	0.5 mm nozzle pressed in or integrated
		including accessories ZBE 08S-02 coupling socket M12x1, angled with 2 m wire, screened
F	Sealing material:	FPM
1	Connecting material:	Stainless steel
200	Cable length:	2 m (standard)

size	Value	Unit
Voltage	14 ... 28	V

 Check the seals at regular intervals - depending on the climatic conditions and the feed chemical - in respect of their serviceability and replace if necessary.

Rotex coupling

Refer to its documentation.

Protective temperature limiter

Type: eBR6000

Tab. 4: Product identification

Code	Property
e	electronic device
B	label for temperature limiter
R	Controller
6	label for device generation
0	Type of ignition protection for measuring sensor input: not intrinsically safe
0	Pt100 3-wire
0	Relay

Technical data - see nameplate and enclosed operating instructions:

"ELMESS protective temperature limiter II (2) G [EEx ib] IIC/IIB II (2) D [Ex ib D] BVS 06 ATEX F 002 X".

Motor design V2 (motor with integrated frequency converter)

Changing the motor voltage and pulse frequency is not permitted.

The motors can be operated within a frequency range of 2 Hz (limited torque) to 100 Hz.

The pulse frequency of the frequency converter is 4 kHz.

Inspection, daily

Check the pump installation for:

- Leaks
- Abnormal noises or squeaks
- Abnormal temperatures
- Abnormal odours
- Abnormal vibrations
- Other anomalies



WARNING!

Stop the pump immediately in the event of any anomalies when inspecting the pump and rectify them immediately. ProMinent Service may be needed if required.

Maintenance

Interval	Maintenance work
	Check whether the seals of the overpressure signalling system are OK and replace in case of doubt.
	Check the effectiveness of the protective temperature limiter for the heating cartridge.
	Check the heating cartridge and the protective temperature limiter for external damage or corrosion to the housing and connecting parts. Immediately have damaged parts rectified with genuine spare parts by the manufacturer.
After 20,000 or 26,000 operating hours (API)	Adhere to the motor manufacturer's recommendations - see operating instructions for the motor.

➔ Screw in the oil drainage plug (2) with a new seal.



WARNING!

Check after 1 day whether the oil drainage plug (2) is still tight.

Power end and motor – ATEX

Data	Value	Unit
Ambient temperature in operation (standard):	-10 ... +40	°C
Ambient temperature in operation ("Low temperature Zone 2" version, for drive):	-20 ... +40	°C

* Only with heating heating cartridge

SS, HC - ATEX liquid end

Data	Value	Unit
Max. temperature, long-term at max. operating pressure	90	°C
Minimum temperature.	-10	°C


Installation height

Data	Value	Unit
Maximum installation height*:	1000	m above standard zero

* We urgently advise you to contact a specialist for ATEX motors with higher intended installation heights!

safety equipment

Other safety equipment - ATEX labels



WARNING!

- The following safety information must be affixed to pumps that contain parts made of electrically non-conducting plastic.
- Ensure that the label is always fitted and legible.
- Do not allow other labels to be stuck over a label.




Fig. 2

Fixed, isolating protective equipment

Secure all these parts in their place when using the pump.

Protective equipment	May only be removed by*:
Motor terminal box cover	ATEX electrical technician, Service
only with ATEX version with add-on power end: Coupling flange inspection cover	Service
only with ATEX version "without motor": Motor connection inspection cover	Service

* Only if required by the operating instructions and if the mains cable remains disconnected from the mains voltage.


Requirements if the motor is being installed independently

The operator must be able to:

- with ATEX motors: perform an ignition hazard assessment

Install the motor - with designs without motor

1. → Select a suitable motor - it must correspond to the data for one of the motors from the "Motor data" table - see Chapter "Technical data".



WARNING!
EX is relevant in areas at risk from explosion!

2. ▶ Fit the motor correctly on the flange (qualified personnel).
Observe the coupling operating instructions!



WARNING!
EX is relevant in areas at risk from explosion!

With a claw coupling: The claw on the motor shaft must be fixed at the correct height, see corresponding figure and table.

3. ▶ As you have converted an "incomplete machine" into a complete machine, you must perform a conformity assessment, risk assessment, issue an EC Declaration of Conformity, fit your own company nameplate, ...
4. ▶ With ATEX pumps: additionally perform an ignition hazard assessment.
5. ▶ Complete the pump documentation / operating instructions.

Declarations of Conformity for the pump

The Declarations of Conformity can be found at the end of the operating instructions.

Special conditions X

If there is an "X" at the end of the ATEX specification of a unit in a "Declaration of Conformity for ATEX Machines" or a "Declaration of Incorporation for ATEX Machines", then special conditions apply for the safe operation of the equipment in areas at risk from explosion.

Please refer in this respect to the operating instructions, design test certificates and other documentation for the bought-in parts!

2.2 Explanation of the ATEX label

in accordance with Directive 2014/34/EU and standards EN ISO 80079-36, -37

Explanation of the pump's ATEX labelling Hydro

Unit group	
II	No mines or associated underground systems, which can be endangered by firedamp - Unit for use in other areas at risk from explosion
Other parameters	
3G Ex h	(Example)
Explosion group	
IIC	for explosion group IIC gas - refer to your explosion protection document
IIB	for explosion group IIB gas - refer to your explosion protection document
Temperature class	
T3	for Temperature class T3 gas - refer to your explosion protection document
T4	for Temperature class T4 gas - refer to your explosion protection document
Equipment protection level (EPL)	

Explanation of the pump's ATEX labelling Hydro						
					Gb	high EPL use possible in zones 1 and 2 - refer to your explosion protection document
					Gc	normal EPL use possible in zone 2 - refer to your explosion protection document
					Suffix X	
					X	Special conditions - refer to the Declarations of Conformity and EC-type examination certificates



WARNING!

Example of EX-designation: Where may I use the ATEX version of the Hydro?


The pump designation is:

" ... II 3G Ex h IIB T4 Gc".

The pump label corresponds to "Unit group" II: the pump may only be used in overground production systems, which are not at risk from firedamp.

The inserted pump label "3G Ex h" does not need to be discussed here.

The additional pump label in the example states "Explosion group" IIB and "Temperature class" T4:

The  *Tab. 5 'Example of the division of gases into explosion groups and temperature classes' on page 27* is shown as an example: the pump can be used for ethyl ether or a comparable gas - refer to the material safety data sheet for the gas or your explosion protection document.

The pump in the example could also be suitable for gases that require only "Explosion group" IIA and "Temperature class" T3, T2 or T1 - but not for T5 and T6.

"EPL" Gc is shown in the next example: Use only in zone 2 – but not in zone 1 or zone 0.

Tab. 5: Example of the division of gases into explosion groups and temperature classes

	T6 85 °C	T5 100 °C	T4 135 °C	T3 200 °C	T2 300 °C	T1 450 °C
IIC	Carbon disulphide	-	Trichlorosilane	-	Ethyne	Hydrogen
IIB	-	-	Ethyl ether	-	Ethene	Mains gas (coal gas)
IIA	-	-	Acetaldehyde	Benzine, Diesel fuel, Aircraft fuel, Heating oils, n-hexane	Ethanol, n-butane, n-butyl alcohol	Acetone, Ammonia, Benzene (pure), Acetic acid, Ethane, Ethyl acetate, Carbon oxide, Methanol, Propane, Toluene



WARNING!

Example 2 - EX-designation: Where may I use the ATEX version of the Hydro?

The pump designation is " ... II 2G Ex h IIC T4 Gb X".

The pump label corresponds to "Unit group" II: the pump may only be used in overground production systems, which are not at risk from firedamp.

The inserted pump label "2G Ex h" does not need to be discussed here.

The pump label is shown in the example "Explosion group" IIC and "Temperature class" T4:

The ↗ *Tab. 5 'Example of the division of gases into explosion groups and temperature classes' on page 27* shows the following: the pump can be used for all gases of "Explosion group" IIC and "Temperature class" T4 - refer to your explosion protection document.

The pump in the example could also be suitable for gases that require only "Explosion group" IIB or IIA and "Temperature class" T3, T2 or T1 – but not for T5 and T6.

"EPL" Gb is shown in the next example: use is possible in zone 1 and zone 2 – but not in zone 0.

"X" indicates "Special conditions" - see EU Declaration of Conformity or type test certification for the pump or additional assemblies. This might involve another lower limit for the ambient temperature, e.g. -10 °C .

3 Storage, transport and unpacking

Safety information



WARNING!

The transporting of pumps which have been used with radioactive feed chemicals is forbidden!

They will also not be accepted by ProMinent!



WARNING!

Only return the metering pump for repair in a cleaned state and with a flushed liquid end - refer to the chapter "Decommissioning"!

Only return metering pumps with a completed Decontamination Declaration form. The Decontamination Declaration constitutes an integral part of an inspection / repair order. A unit can only be inspected or repaired when a Declaration of Decontamination Form is submitted that has been completed correctly and in full by an authorised and qualified person on behalf of the pump operator.

The "Decontamination Declaration Form" can be found at www.prominent.com.



WARNING!

Slings can tear

ProMinent only supplies "non-reusable slings" in accordance with DIN EN 60005. They can tear with repeated use.

- Destroy and remove the slings as soon as the pump has been lifted into its final position.



CAUTION!

Danger of environmental and material damage

The unit can be damaged or oil may escape due to incorrect or improper storage or transportation!

- The unit should only be stored or transported in a well packaged state - preferably in its original packaging.
- Only transport the unit with the locking screw - not the bleed plug - fitted to the oil filling opening.
- The packaged unit should also only be stored or transported in accordance with the stipulated storage conditions.
- The packaged unit should be protected from moisture and the ingress of chemicals.



CAUTION!

Danger of environmental damage

Pumps with a liquid end are supplied filled with oil.

- When transporting, take care that no oil escapes.

Storage

Personnel: ■ Technical personnel

1. ► Plug the caps on the valves.
2. ► Check whether the sealing screw is in place on the oil filler neck.
3. ► Preferably place the pump standing vertically on a pallet and secure against falling over.
4. ► Cover the pump with a tarpaulin cover - allowing rear ventilation.

Store the pump in a dry, sealed place under the ambient conditions according to chapter "Technical Data".

Ambient conditions

- refer to "Technical Data" chapter.

4 Overview of equipment / control elements




Fig. 3: Hydro, single head and double head versions

- A Power end
- B Hydraulic end
- C Liquid end
- 1 Stroke adjustment dial
- 2 Safety relief valve
- 3 Oil inspection window

- 4 Gearbox vent stopper
- 5 Oil drain stopper
- 6 Oil drainage plug
- 7 Stroke sensor (optional)
- 8 Diaphragm rupture sensor




Fig. 4: Liquid end

- 1 Discharge valve
- 2 Diaphragm mounting plate
- 3 Diaphragm rupture sensor
- 4 Dosing head
- 5 Suction valve

5 Functional description

Pump

The metering pump is an oscillating diaphragm pump, the stroke length of which can be adjusted. An electric motor drives the pump.

Hydraulic end

The hydraulic end has a fixed safety relief valve (5). The safety relief valve provides protection for the pump power end and the diaphragm if the liquid feed pressure becomes too high. If the discharge side of the liquid end is blocked, the safety relief valve (5) opens at a real opening pressure and allows the hydraulic oil to flow into the power end housing. The real opening pressure lies above the nominal pressure (the pressure stage) – see chap. "Technical Data".

This does not guarantee protection of the system against overpressure!

6 Assembly



- Compare the dimensions on the dimensional drawing with those of the pump.

Install the motor - with designs without motor

1. → Select a suitable motor - it must correspond to the data for one of the motors from the "Motor data" table - see Chapter "Technical data".

**WARNING!**

EX is relevant in areas at risk from explosion!

2. → Fit the motor correctly on the flange (qualified personnel).
Observe the coupling operating instructions!

**WARNING!**

EX is relevant in areas at risk from explosion!

With a claw coupling: The claw on the motor shaft must be fixed at the correct height, see corresponding figure and table.

3. → As you have converted an "incomplete machine" into a complete machine, you must perform a conformity assessment, risk assessment, issue an EC Declaration of Conformity, fit your own company nameplate,
4. → With ATEX pumps: additionally perform an ignition hazard assessment.
5. → Complete the pump documentation / operating instructions.




Fig. 5: Correct height of the clutch claw on the motor shaft

Tab. 6: Hydro HP2

Size	Motor flange	Q
	56C	2.06" 52.32
80	200	50
71	B5, 160	30

Dimensions in mm - unless otherwise indicated.

Tab. 7: Hydro HP3

Size	Motor flange	Q
	56C	2.06" 52.32
80	200	50
80*	B 14, Ø 160	40

Dimensions in mm - unless otherwise indicated.

* The inner diameter of the shaft is 19 mm!

Base




Fig. 6



WARNING!

Danger of electric shock

If water or other electrically conducting liquids penetrate into the drive housing, in any other manner than via the pump's suction connection, an electric shock may occur.

- Position the pump so that it cannot be flooded.



WARNING!

The pump can break through the base or slide off it

- Ensure that the base is horizontal, flat and permanently load-bearing.



Capacity too low

Vibrations can disturb the liquid end valves.

- Do not allow the base to vibrate.

Space requirement




Fig. 7



WARNING!

Motor may overheat

If the necessary cooling air supply is not guaranteed, the motor may overheat. In an area at risk from explosion, it could trigger an explosion.

- Maintain sufficient clearance between the air intake opening and the walls. The distance should be greater than 1/4 of the diameter of the air intake opening.
- The fan must not suck in the exhaust air from other devices.



CAUTION!

Danger from incorrectly operated or inadequately maintained pumps

Danger can arise from a poorly accessible pump due to incorrect operation and poor maintenance.

- Ensure that the pump is accessible at all times.
- Adhere to the maintenance intervals.



WARNING!


Risk of burns with hot feed chemicals

If hot feed chemicals can heat the liquid ends above the permissible surface temperatures, persons can suffer burns from them.

- Consider attaching a "Hot surface" label to the liquid end or ...
- fitting a guard plate.

Position the pump so that control elements, such as the stroke length adjustment knob, the indicating dial A or the oil inspection window, are accessible.

Make sure that there is enough space to carry out an oil change (vent screws, oil drainage plugs, oil trough ...).



- 1 Discharge valve
- 2 Dosing head
- 3 Suction valve

Ensure there is sufficient free space (f) around the dosing head as well as the suction and discharge valve so that maintenance and repair work can be carried out on these components.

Fig. 8

Liquid end alignment



Capacity too low

The liquid end valves cannot close correctly if they are not upright.

- Ensure that the discharge valve is upright.

Fastening



Capacity too low

Vibrations can disturb the liquid end valves.

- Secure the metering pump so that no vibrations can occur.




Fig. 9

1. Take the dimensions (m) for the fastening holes from the appropriate dimensional or data sheets.
2. Fix the pump base to the supporting floor with sufficient strong screws.

With externally mounted pumps fix the frame to the supporting floor with sufficient strong screws.

7 Installation

**CAUTION!****Danger of injury to personnel and material damage**

Disregarding the technical data during installation can lead to personal injuries or damage to property.

- Observe the technical data - refer to the "Technical data" chapter and, where applicable, the operating instructions for the accessories.

7.1 Installation, hydraulic

**WARNING!****ATEX pumps in areas at risk from explosion**

- Metering pumps in areas at risk of explosion are provided, as a matter of course, with an appropriate safety relief valve on the outlet side of the metering pump (which is used to protect against excessive heating due to overloading and impact sparks caused by the breakage of power end parts triggered by overloading.)
- Likewise a temperature monitor or a pressure side flow control is to be fitting to metering pumps with hydraulic diaphragm control for T4. (Protection against impermissible heating up in the event of continuous operation by the internal relief valve).
- Should the various components have differing temperature classes, scope for using the complete pump depends on the component with the lowest temperature class.
- Hydraulic diaphragm pumps are highly suitable, although the design with Ex "i" diaphragm rupture sensor and a pressure-side flow control is required.
- Ensure that installations in areas at risk of explosion are checked by a "recognised competent" person.
- Please note the relevant national regulations during installation!

**WARNING!****Risk of fire with flammable feed chemicals**

- Combustible media may only be transported using stainless steel or Hastelloy C dosing heads.
- Metering pumps can be used for metering combustible media, however as a matter of principle only of a design including ATEX diaphragm rupture sensors and a pressure-side flow control.
- During filling and draining of the liquid end, an expert must ensure that feed chemical does not come into contact with air.
- If necessary, the operator must implement further measures.



WARNING!

Warning of feed chemical reactions to water

Feed chemicals that should not come into contact with water may react to residual water in the liquid end that may originate from works testing.

- Blow the liquid end dry with compressed air through the suction connector.
- Then flush the liquid end with a suitable medium through the suction connector.



WARNING!

The following measures are an advantage when working with highly aggressive or hazardous feed chemicals:

- Install a bleed valve with recirculation in the storage tank.
- Install an additional shut-off valve on the discharge or suction ends.



CAUTION!

Warning of backflow

A back pressure valve or a spring-loaded injection valve do not represent absolutely leak-tight closing elements.

- For this purpose use a shut-off valve, a solenoid valve or a vacuum breaker.



CAUTION!

Suction problems are possible

The valves may no longer close properly with feed chemicals with a particle size of greater than 0.3 mm.

- Install a suitable filter in the suction line.



CAUTION!

Warning of the discharge line rupturing

With a closed discharge line (e.g. due to a clogged discharge line or by closing a valve), the pressure that the metering pump generates can reach several times more than the permissible pressure of the system or the metering pump. This could lead to lines bursting resulting in dangerous consequences with aggressive or hazardous feed chemicals.

- Install a relief valve that limits the pressure of the pump to the maximum permissible operating pressure of the system.



CAUTION!

Warning of the discharge line rupturing

Hose lines with insufficient pressure rating may rupture.

- Only use hose lines with the required pressure rating.



CAUTION!

Uncontrolled flow of feed chemical

Feed chemical may press through a stopped metering pump if there is back pressure.

- Use an injection valve or a vacuum breaker.



CAUTION!

Uncontrolled flow of feed chemical

Feed chemical may press through the metering pump in an uncontrolled manner in the event of excessive priming pressure on the suction side of the metering pump.

- Do not exceed the maximum permissible priming pressure for the metering pump or
- set up the installation properly.



CAUTION!

Warning about lines coming loose

Suction, discharge and relief lines installed incorrectly can come loose from the pump connection.

- Only use original hoses with the specified hose diameter and wall thickness.
 - Only use clamp rings and hose nozzles that fit the respective hose diameter.
 - Always connect the lines without mechanical tension.
- Only connect steel piping via a flexible piping section to a plastic valve body - see the following figure.




Fig. 10: Connect the steel piping to the plastic pump body as shown

- 1 Steel piping
- 2 Flexible pipe section
- 3 Plastic valve body




Fig. 11: Moulded composite seals with corrugated insert



CAUTION!

Warning of leaks

Leaks can occur on the pump connection depending on the insert used.

- The pump is supplied with PTFE moulded composite seals with a flare, which are used for the pump connectors, which seal the connectors between grooved pump valves and ProMinent grooved inserts - see Fig. 11.
- However, in the event that a smooth insert is used (e.g. third party part), an elastomer flat seal must be used - see Fig. 12.




Fig. 12: Elastomer flat seal for a smooth insert



CAUTION!

Warning of feed chemical spraying around

PTFE seals, which have already been used / compressed, can no longer reliably seal a hydraulic connection.

- New, unused PTFE seals must always be used.



CAUTION!

Danger due to incorrect use of the pressure relief valve

The pressure relief valve can only protect the motor and the gear, and then only against impermissible excess pressure caused by the metering pump itself. It cannot protect the system from excess pressure.

- Use other mechanisms to protect the motor and gear from impermissible excess pressure from the system.
- Use other mechanisms to protect the system from impermissible excess pressure.



- *Precise metering is only possible when the back pressure is maintained above 1 bar at all times.*
- *If metering at atmospheric pressure, a back pressure valve should be used to create a back pressure of approx. 1.5 bar.*

Diaphragm rupture sensor



CAUTION!

Warning of unnoticed diaphragm rupture

Only above approximately 2 bar system back pressure is a signal generated in the event of diaphragm rupture.

- Only rely on the diaphragm rupture sensor with back pressures of greater than 2 bar.

7.1.1 Basic installation notes

Safety information



CAUTION!

Danger from rupturing hydraulic components

Hydraulic components can rupture if the maximum permissible operating pressure is exceeded.

- Never allow the metering pump to run against a closed shut-off device.
- With metering pumps without integral relief valve: Install a relief valve in the discharge line.



CAUTION!

Hazardous feed chemicals can escape

With hazardous feed chemicals: Hazardous feed chemical can leak out when using conventional bleeding procedures with metering pumps.

- Install a bleed line with return line into the storage tank.

➔ Shorten the return line so that it is not immersed in the feed chemical in the storage tank.




Fig. 13: (A) standard installation, (B) with pulsation damper

- 1 Main line
- 2 Storage tank

Legend for hydraulic diagram

Symbol	Explanation	Symbol	Explanation
	Metering pump		Foot valve with filter mesh
	Injection valve		Level switch
	Back pressure valve or safety valve		Manometer

7.2 Installation, electrical



WARNING!

ATEX pumps in areas at risk from explosion

- Only connect potential-free as well as non-isolating low voltage switch accessories, such as diaphragm rupture indicators, stroke rate instruments etc., to an intrinsically safe power circuit in areas at risk from explosion.
- If several electrical components are connected together, the safety of the entire connected system has to be tested and confirmed in terms of its safety. This can either be in the form of a Declaration of Conformity from the supplier (ProMinent) for the entire unit or, if individual components are supplied, in the form of the operator's explosion protection document.
- Only motor protection switches, mains switches and fuses permitted for use in areas at risk of explosion in line with the manufacturer's information may be used as electrical components in areas at risk of explosion.
- Electrically connect the electrical units listed on the earthing diagram in the appendix, cleanly and permanently, to an electrically clean earthing point, - e.g. with an earthing bar on your system.
- Electrically connect the electrical units fitted with a potential equalisation cable to each other, cleanly and permanently, to an electrically clean potential equalisation point - e.g. with a potential equalisation bar on your system.
- Note the enclosed documentation for the individual electrical components.
- Please note the relevant national regulations during installation!



WARNING!

Danger of electric shock

Unprofessional installation may lead to electric shocks.

- Crimp cable end sleeves onto all shortened cable cores.
- Only technically trained personnel are authorised to undertake the electrical installation of the device.



WARNING!

Danger of electric shock

In the event of an electrical accident, it must be possible to quickly disconnect the pump, and any electrical ancillaries which may possibly be present, from the mains.

- Install an emergency cut-off switch in the mains supply line to the pump and any electrical ancillaries which may be present or
- Integrate the pump and electrical ancillaries which may be present in the emergency cut-off management of the system and inform personnel of the isolating option.



WARNING!

Danger of electric shock

This pump is equipped with a protective earth conductor, to reduce the risk arising from an electric shock.

- Connect the PE conductor to "earth" with a clean and permanent electrical connection.



WARNING!

Danger of electric shock

A mains voltage may exist inside the motor or electrical ancillaries.

- If the housing of the motor or electrical ancillaries has been damaged, you must disconnect it from the mains immediately. The pump must only be returned to service after an authorised repair.

What requires electrical installation?:

- Motor
- External fan (identity code option)
- Frequency converter (identity code option)
- Stroke control drive (identity code option)
- Stroke actuator (identity code option)
- Diaphragm rupture sensor (standard)
- Stroke sensor (identity code option)
- Heating cartridge (identity code option)
- Protective temperature limiter (identity code option)
- Earthing wires (to be installed by the site operator, compulsory in the area at risk from explosion)
- Potential equalisation line (to be provided on site, prescribed in the area at risk from explosion)

Motor




Fig. 14: Direction of rotation of motor



WARNING!

ATEX pumps in areas at risk from explosion

- Use a suitable motor protection switch to protect power end motors. Use motor protection approved for this application with Ex"e" motors. (Protection against warming caused by overloading)
- Provide a time-delay residual current device.
- Ensure that motors are only installed and checked in areas at risk from explosion by a "recognised competent" person.
- Cleanly earth the motor via the mains cable.
- Observe the enclosed operating instructions for the Ex motor, especially the maintenance plan.



WARNING!

Only motors with a frequency converter: Danger of electric shock

The danger of electric shock remains for 3 minutes after the mains voltage has been switched off on conducting parts of the motor with an integrated frequency converter and on the lines themselves.

- After switching off, allow the device to stand for 3 minutes before opening the terminal box.



CAUTION!

The motor can be damaged

Provide appropriate motor protection devices (e.g. motor protection switch with thermal overcurrent trip) to protect the motor from overloading. Fuses do not provide motor protection.



CAUTION!

Only motors with a frequency converter: The motor can be damaged

The input current limiter could be damaged if a motor with an integrated frequency converter is restarted within 3 minutes of the mains voltage being switched off.


- After switching off, allow the device to stand for at least 3 minutes before restarting.
- If the motor is controlled via a control, take this into consideration at the control.



CAUTION!




Pump can be damaged

The pump can be damaged if the motor drives the pump in the wrong direction.

- Note the correct direction of rotation indicated by the arrow on the fan cover when connecting the motor, as shown in  'Motor' on page 43.



Use an electrical isolating device in the mains supply cable, such as a mains switch, to de-energise the pump independently of the entire installation (e.g. for repairs).

1.  Install a motor protection switch, as the motors have no fuse.
2.  Install an emergency cut-off switch or include the motor in the system's emergency cut-off management scheme.
3.  Only connect the motor to the power supply using a suitable cable.



- *Key motor data can be found on the nameplate and in the "Technical data" chapter.*
- *The terminal wiring diagram is located in the terminal box.*



Motor data sheets, special motors, special motor flanges, external fan, temperature monitoring

- Further information on motors can be found on our website www.prominent.com.
- Motor data sheets can also be requested for the motors.
- With motors other than those with identity code specifications "S", "M" or "N": Pay special attention to the operating instructions for the motors.
- Special motors or special motor flanges are available on request.

External fan



CAUTION!

Provide a separate power supply for the external fan for motors with external fans (identity code specification "R" or "Z").

Variable speed motors with frequency converter

Connect the motor as per the wiring diagram for the controller, if it is controlled by an electronic control unit (such as 3-phase AC motors by a frequency converter).

Stroke length actuators / control power ends

Connect the motors in accordance with the enclosed wiring diagram or as per the wiring diagram fixed to the inside of the housing.



CAUTION!

Only operate stroke length actuators / control drives when the pump is running.

Otherwise they will become damaged.

Diaphragm rupture sensor (optional)



WARNING!

Danger of electric shock

In the event of a defect, there is a danger of electric shock if conductive feed chemicals are present.

- For safety reasons, we recommend connecting to protective low voltage, e.g. in accordance with EN 60335-1 (SELV).



WARNING!

Risk of fire after a diaphragm rupture

Make sure that the electric diaphragm rupture sensor switches off the pump immediately after a diaphragm rupture.

- Connect the pump and the diaphragm rupture sensor to a control so that the pump stops immediately in the event of a diaphragm rupture.



CAUTION!

Danger resulting from unnoticed diaphragm rupture

If the pump has been ordered with an electric diaphragm rupture sensor, it must also be electrically installed.

- Electrically wire the enclosed diaphragm rupture sensor to a suitable monitoring device.



CAUTION!

Additional damage with a ruptured diaphragm

Never allow the diaphragm to rupture fully if damage can be caused by hydraulic oil mixing with the feed chemical.

- The diaphragm rupture sensor must switch off the pump immediately.
Only restart the pump once the diaphragm has been replaced.

a) Diaphragm rupture sensor with switch contact



- *The cable can be connected as required.*

b) Namur sensor, inherently safe

Make sure that the monitoring/feed equipment installed by the customer is capable of evaluating the current variations of the Namur sensor to indicate a diaphragm rupture!



WARNING!

The following applies in areas at risk from explosion:

- Note the details of the type examination certificate PTB 00 ATEX 2048 X for the Namur sensor NJ1.5-8GM-N as well.

When using flammable media:



WARNING!

Risk of fire after a diaphragm rupture

Make sure that the electric diaphragm rupture sensor switches off the pump immediately after a diaphragm rupture.

- Connect the pump and the diaphragm rupture sensor to a control so that the pump stops immediately in the event of a diaphragm rupture.

Stroke sensor (optional)

- Connect the stroke sensor to a suitable monitoring device in line with the details in the "Technical data" chapter - also refer to their technical data!

Make sure that the monitoring/feed equipment installed by the customer is capable of evaluating the current variations of the Namur sensor to indicate a diaphragm rupture!

**WARNING!****The following applies in areas at risk from explosion:**

- Note the details of the type examination certificate PTB 00 ATEX 2048 X for the Namur sensor NJ1.5-8GM-N as well.

Heating cartridge

- ➔ Install the heating cartridge in line with its documentation. It must only be connected to the supplied power supply or the protective temperature limiter (for ATEX)!

Earthing lines

Connect the electrical components of the entire installation supplied cleanly and permanently to an electrically clean earthing point, e.g. with an earthing bar on site - see earthing diagrams in the appendix.

Potential equalisation lines (mandatory with ATEX)

The entire installation supplied is provided ex works with the necessary potential equalisation lines. Electrically connect an additional potential equalisation cable from the potential equalisation cables from this system cleanly and permanently to an electrically clean potential equalisation point, e.g. to a potential equalisation bar on site.

Other units

- ➔ Install the other units in line with their documentation.

8 Start up and operation

Safety information



WARNING!

ATEX pumps in areas at risk from explosion

- Make sure that a suitably competent person checks whether the appropriate installation information from the "Installation " chapter has been implemented correctly.
- Make sure that a "recognised competent person" checks the electrical installation and in particular the intrinsically safe power circuits.
- Set the opening pressure of the relief valve at a maximum of no more than 1.5 times the rated pressure of the pump.



WARNING!

Fire hazard with flammable media

Only with flammable media: They can be ignited by oxygen.

- The pump may not work if there is a mixture of feed chemical with oxygen in the liquid end. A specialist may need to take appropriate actions (using inert gas, ...).



WARNING!

Hot surface

In event the power end motor is loaded excessively, its surface may become very hot.

- Avoid contact.
- If necessary, mount a guard plate.



WARNING!

Risk of burns with hot feed chemicals

If hot feed chemicals can heat the liquid ends above the permissible surface temperatures, persons can suffer burns from them.

- Consider attaching a "Hot surface" label to the liquid end or ...
- fitting a guard plate.



WARNING!

Only motors with a frequency converter: Danger of electric shock

The danger of electric shock remains for 3 minutes after the mains voltage has been switched off on conducting parts of the motor with an integrated frequency converter and on the lines themselves.

- After switching off, allow the device to stand for 3 minutes before opening the terminal box.

**CAUTION!**

Only motors with a frequency converter: The motor can be damaged

The input current limiter could be damaged if a motor with an integrated frequency converter is restarted within 3 minutes of the mains voltage being switched off.

- After switching off, allow the device to stand for at least 3 minutes before restarting.

**CAUTION!**

Feed chemical could escape

- Check suction and discharge lines, and liquid end with valves, for leak-tightness and tighten if necessary.
- Check whether the necessary flushing pipes or bleed lines are connected.

**CAUTION!**

Prior to commissioning, check that the power end motor and corresponding ancillary equipment is connected in compliance with the regulations!

**CAUTION!**

Adhere to the instructions in the frequency converter operating instructions when using pumps with speed control

Observe the technical data**CAUTION!**

Danger of material damage

Observe the details in the chapter "Technical data" (pressure, viscosity, resistance, etc.).

Test the diaphragm rupture sensor**CAUTION!**

Feed chemical can escape unnoticed

If the diaphragm rupture sensor does not stop the pump or no alarm is triggered, feed chemical can escape unnoticed.

- Trigger the diaphragm rupture indicator - refer to the "Repair" chapter and, in so doing, check the reaction of the analysis unit and/or the pump.

**CAUTION!**

The pump should only be restarted once the diaphragm has been replaced after a diaphragm rupture, if damage can be caused by hydraulic oil mixing with the feed chemical.

Pressure relief valve



CAUTION!

Never adjust the pressure relief valve.

Checking the direction of rotation

When commissioning the unit, check whether the drive motor is rotating correctly - check this against the arrow on the motor housing or the diagram in the chapter entitled "Electrical Installation."



WARNING!

Risk of injury from the fan impeller

The fan impeller beneath motor's fan cowling can cause severe injuries while it is turning.

- The pump must only be connected to the mains voltage with the fan cowling closed.

Installing a vent screw

Replace the sealing screw at the oil filler neck with the vent screw supplied - refer to the chapter entitled "Overview of equipment and control elements".



Slight oil marks on the pump do not indicate leaks with a new product.

- *Wipe away and note down oil positions. Only contact the supplier if it reoccurs.*

Use a safety relief valve



CAUTION!

Danger due to incorrect use of the safety relief valve

The safety relief valve can only protect the motor and the gear, only against illegal positive pressure that is monitored by the metering pump itself. It cannot protect the system against positive pressure.

- Protect the motor and gear of the system against positive pressure using other mechanisms.
- Protect the system against illegal positive pressure using other mechanisms.

The actual opening pressure is above the nominal pressure (the pressure stage) - refer to the "Technical data" chapter.

Checking the oil level

When the pump is idle, check whether the oil level in the pump is in the middle of the oil level indicator.

This will rule out the pump losing oil and suffering damage.

Avoid particles



For chemicals with a particle size greater than 0.3 mm, the valves may no longer close properly.

- *Install a suitable filter in the suction line.*

Setting the relief valve

Only in areas at risk from explosion: Set the opening pressure of the relief valve at a maximum of no more than 1.5 times the rated pump pressure .

Only with a heating cartridge: check the action of the heating cartridge

Check the heating action of the heating cartridge and the effectiveness of the protective temperature limiter. No overheating must occur, especially in the area at risk from explosion!

Only at low temperatures: allow the pump to warm up

1. ➤ Switch on the heating cartridge, set the stroke length of the pump to "0" and start the pump.
2. ➤ Allow the pump to warm up for 5 minutes.
3. ➤ Set the stroke length of the pump to the required value.

Earthing lines

Check whether the earthing lines in the pump's electrical units are correctly connected and connected to a clean earth wire - see earthing diagrams in the appendix.

Potential equalisation lines (mandatory with ATEX)

Check whether the potential equalisation lines are sitting correctly on the pump and connected to a clean potential equalisation point.

8.1 Bleeding the liquid end

When bleeding the liquid end or priming against pressure:

Depressurise the suction and discharge lines!

With dangerous or unknown feed chemicals, take suitable protective measures according to the safety data sheet!

1. ➤ Loosen the discharge line.
2. ➤ Install a piece of translucent hose.
3. ➤ Run the pump slowly until the feed chemical appears in the section of hose.
4. ➤ Remove the piece of hose.
5. ➤ Assemble the discharge line.




Fig. 15: Tapping the valve set disc



Eliminating suction problems (only for single ball valves with PTFE ball seat)

For suction problems occurring during start up:

- Exclude the possibility that there are foreign bodies in the valve.
- Place the valve on a stable surface.
- Using a hammer (1) and a brass bar (2), gently tap the PTFE ball seat above the valve ball - see figure below.
- Then with the valve in a damp condition allow it to prime.

8.2 Calibrate the stroke control drive (optional)

The stroke control drive is calibrated to the capacity ordered ex-factory. Please contact ProMinent in the event that you want the stroke control drive to be calibrated to another capacity.

9 Maintenance

Safety information



WARNING!

ATEX pumps in areas at risk from explosion

- Carry out a general check to ensure that the system is working properly, particularly the power end and bearings, by regularly monitoring it (for leaks, noises, temperatures, smell, etc.).
- Do not allow the pump to run hot due to a lack of oil. With lubricated metering pumps, regularly check for the presence of lubricant, for example by checking the liquid level, visual leak control etc. If oil is leaking, examine the leakage point immediately and eliminate the cause.
- Check the correct operation of the relief valve downstream of the pump. In premises at risk from explosion, the relief valve should prevent the gear from becoming overloaded and becoming hot.
- Observe the enclosed operating instructions for the Ex motor.
- Only with pumps with a motor flange: replace worn gear ring etc. of the clutch.
- Only with add-on power end: replace worn gear ring/DZ element of the clutch.
- When cleaning plastic components, ensure that no electrostatic charges are generated by excessive friction. - see warning label.
- Always earth the discharge line and the suction line against the pump to prevent electrostatic charge before working on the pump.
- Replace wear parts, such as bearings, when there is an identifiable incidence of unacceptable wear. (The nominal service life cannot be calculated with lubricated bearings.)
- Check whether the potential equalisation lines are all sitting correctly with clean contacts.
- Check whether the earth lines are all sitting correctly with clean contacts. Use the earthing drawings as an aid – see Appendix.
- Only use genuine spare parts as replacements.
- A diagnostic device for bearing damage is very useful for the premature detection of bearing damage.
- Carry out inspections and repair in compliance with DIN EN IEC 60079-17 and ensure that they are only performed by "experienced personnel with the requisite knowledge".
- These measures are deemed to be minimum protection measures by ProMinent. It is the duty of the operator to take appropriate measures to eliminate any further hazards known to him.



WARNING!

ATEX pumps in areas at risk from explosion

Static electricity can cause ignition sparks.

- Consider potential equalisation before you approach any pump equipment that could be at a different electrical potential (such as pipes or tools)



WARNING!

Fire hazard with flammable media

Only with flammable media: They can be ignited by oxygen.

- The pump may not work if there is a mixture of feed chemical with oxygen in the liquid end. A specialist may need to take appropriate actions (using inert gas, ...).



WARNING!

It is mandatory that you read the safety information and specifications in the "Storage, Transport and Unpacking" chapter prior to shipping the pump.



CAUTION!

Warning of feed chemical spraying around

Feed chemical can spray out of the hydraulic components if they are manipulated or opened due to pressure in the liquid end and adjacent parts of the system.

- Disconnect the pump from the mains power supply and ensure that it cannot be switched on again by unauthorised persons.
- Depressurise the system before commencing any work on hydraulic parts.



WARNING!

Warning of hazardous feed chemical

Should a dangerous feed chemical be used: it may escape from the hydraulic components when working on the pump, material failure or incorrect handling of the pump.

- Take appropriate protective measures before working on the pump (e.g. safety glasses, safety gloves, ...). Adhere to the material safety data sheet for the feed chemical.
- Drain and flush the liquid end before working on the pump.



WARNING!

Danger of an electric shock

When working on the motor or electrical auxiliary equipment, there is a danger of an electric shock.

- Before working on the motor, take note of the safety instructions in its operating instructions!
- Should external fans, servomotors or other auxiliary equipment be installed, these should also be disconnected and checked that they are voltage free.



Under heavy loading (e.g. continuous operation) shorter maintenance intervals are recommended than those given.



Third-party spare parts for the pumps may result in problems when pumping.

- *Only use original spare parts.*
- *Use the correct spare parts kits. In the event of doubt, refer to the exploded views and ordering information in the appendix.*

Inspection, daily

Check the pump installation for:

- Leaks
- Abnormal noises or squeaks
- Abnormal temperatures
- Abnormal odours
- Abnormal vibrations
- Other anomalies



WARNING!

In the area at risk from explosion:

stop the pump immediately and rectify these anomalies. ProMinent Service may be needed if required.

Maintenance work:

Interval	Maintenance work	Personnel
Quarterly*	<ul style="list-style-type: none"> ■ ATEX pump only: Special maintenance work - refer to the "Safety information for ATEX pumps". ■ Only pumps with add-on power end or "without motor" and/or with motor flange: Check the gear ring/DZ element of the ROTEX® coupling as per their manual. Open the inspection window on the flange to check. Close it again! If the coupling is OK, the maintenance interval can be increased to 4000 hours. ■ If the coupling is not clearly OK: Call ProMinent Service. 	Technical personnel
	ATEX pump only: Check the seals of the EDS 4448 pressure switch at regular intervals (depending on the climatic conditions and the feed chemical) in respect of their serviceability and replace if necessary.	Technical personnel
	Check the correct seating and state of the metering lines at both discharge and suction ends.	Technical personnel
	Check that the discharge valve and suction valve are fitted tightly.	Technical personnel
	Check whether the diaphragm rupture sensor stops the pump or generates an alarm after it is triggered, see the chapter "Repairs".	Technical personnel
	Check that the diaphragm rupture sensor is firmly seated.	Technical personnel
	Check whether the overpressure signalling triggers when an overpressure exists.	Technical personnel
	Check the secure seating of the overpressure signaller.	Technical personnel
	Check the secure seating of the pressure limitation valve (50 Nm).	Technical personnel
	With the pump running, check whether bubbles rise in the window of the bleed valve.	Technical personnel
	Check that the flow is correct: Allow the pump to prime briefly.	Technical personnel
	Check the leak-tightness of the entire liquid end - particularly around the leakage hole!	Technical personnel
	Check that the dosing head screws are tight.	Technical personnel
	Check that the electrical connectors are intact.	Electrician Electrical technician with additional explosion protection qualification
	Check the tight, clean electrical connection of the earthing wires.	Electrician Electrical technician with additional explosion protection qualification
Check the tight, clean electrical connection of the potential equalisation wires.	Electrician Electrical technician with additional explosion protection qualification	
Check the oil level.	Technical personnel	

Interval	Maintenance work	Personnel
After approx. 4000 operating hours	Check the gear ring/DZ element of the coupling as per their operating instructions.	Technical personnel
After approx. 5,000 operating hours	Change hydraulic oil - refer to "Changing hydraulic oil" in this chapter.	Instructed personnel
	Check whether the seals of the overpressure signalling system are OK and replace in case of doubt.	Technical personnel
	ATEX design only: Check the effectiveness of the protective temperature limiter for the heating cartridge.	Technical personnel
	ATEX design only: Arrange for immediate rectification of any outwardly apparent damage or corrosion on parts of the housing and on connecting parts of the heating cartridge or protective temperature limiter by the manufacturer using original spare parts.	Customer Service department
After approx. 10,000 operating hours **	Diaphragm change - refer to "Changing the diaphragm" in the "Repair" chapter.	Technical personnel
After approx. 20,000 operating hours	Follow the motor manufacturer's recommendations - see operating instructions for the motor.	

* Under normal loading (approx. 30% of continuous operation).

Under heavy loading (e.g. continuous operation): Shorter intervals.

** under normal loading. With very unfavourable metering parameters: Shorter intervals.

Changing the hydraulic oil



WARNING!

Risk of burns due to hot hydraulic oil

The hydraulic oil may become very hot when the pump is exposed to extensive loading.

- When draining oil, avoid contact with the oil running out.



WARNING!

If the pump must be operated using hydraulic oil compatible with foodstuffs, then only foodsafe hydraulic oil must be used.

Draining the hydraulic oil

For the double head versions, perform the following work simultaneously on both dosing heads.

1. ➤ Set the stroke adjustment dial (2) to "0".
2. ➤ Unscrew the gearbox vent stopper (3).
3. ➤ Place an oil trough under the oil drainage plug (5).
4. ➤ Unscrew the oil drainage plug (5) from the power end housing.
5. ➤ Allow the hydraulic oil to run out of the drive.
6. ➤ Place an oil trough under the hydraulic end.
7. ➤ Unscrew the oil drainage stopper (4) out of the hydraulic end.
8. ➤ Allow the hydraulic oil to run out of the hydraulic end.
9. ➤ Screw on the oil drainage plug (5).
10. ➤ Screw in the oil drainage stopper (4) with a new seal.




Fig. 16

Fill with hydraulic oil

For the double head versions, perform the following work simultaneously on both dosing heads.

1. ➤ Set the stroke adjustment dial (2) to "100%" and open the safety relief valve (1) - tighten the knurled screw.
2. ➤ Slowly fill hydraulic oil through the opening for the gearbox vent stopper (3) until the oil inspection window (6) is covered:

Type	Level of covering
HP2	1/3
HP3	1/3

3. ➤ Start the pump.
4. ➤ Allow the pump to run slowly for a further 1... 2 minutes.
5. ➤ Top up with hydraulic oil if necessary.
6. ➤ Screw the gearbox vent stopper (3) back in. Do not close the bleed valve!
7. ➤ Close the safety relief valve (1) - loosen the knurled screw.
8. ➤ Check whether all openings are tightly sealed again – especially in the area at risk from explosion!



WARNING!

Only in areas at risk from explosion: Check after 1 day whether the oil drainage stopper (4) and the oil drainage plug (5) are still tight.

10 Repair

Safety information

**WARNING!****ATEX pumps in the ATEX area**

- Carry out a general check to ensure that the system is functioning properly, particularly the power end and bearings, by regular monitoring (for leaks, noises, temperatures, smell, etc.).

**WARNING!****ATEX pumps in areas at risk from explosion**

Static electricity can cause ignition sparks.

- Consider potential equalisation before you approach any pump equipment that could be at a different electrical potential (such as pipes or tools)

**WARNING!****Fire hazard with flammable media**

Only with flammable media: They can be ignited by oxygen.

- The pump may not work if there is a mixture of feed chemical with oxygen in the liquid end. A specialist may need to take appropriate actions (using inert gas, ...).

**WARNING!**

It is mandatory that you read the safety information and specifications in the "Storage, Transport and Unpacking" chapter prior to shipping the pump.

**CAUTION!****Warning of feed chemical spraying around**

Feed chemical can spray out of the hydraulic components if they are manipulated or opened due to pressure in the liquid end and adjacent parts of the system.

- Disconnect the pump from the mains power supply and ensure that it cannot be switched on again by unauthorised persons.
- Depressurise the system before commencing any work on hydraulic parts.

**WARNING!****Warning of hazardous feed chemical**

Should a dangerous feed chemical be used: it may escape from the hydraulic components when working on the pump, material failure or incorrect handling of the pump.

- Take appropriate protective measures before working on the pump (e.g. safety glasses, safety gloves, ...). Adhere to the material safety data sheet for the feed chemical.
- Drain and flush the liquid end before working on the pump.



WARNING!

Risk of fingers being crushed

Under unfavourable conditions, the stroke axle or displacement body can cause crushing of the fingers.

- Disconnect the pump from the mains power supply and ensure that it cannot be switched on again by unauthorised persons.



WARNING!

Risk of injury from the fan impeller

The fan impeller beneath motor's fan cowling can cause severe injuries while it is turning.

- The pump must only be connected to the mains voltage with the fan cowling closed.



WARNING!

Hot oil and hot components

The hydraulic oil and the hydraulic end may become very hot when the pump is exposed to heavy loading.

- Allow the pump to cool before starting work.



CAUTION!

Never adjust the pressure relief valve.



Unsuitable spare parts for the valves may lead to problems for the pumps.

- *Only use new components that are especially adapted to fit your valve (both in terms of shape and chemical resistance).*
- *Use the correct spare parts kits. If in doubt, refer to the exploded views and ordering information on our website www.prominent.com.*



Unsuitable spare parts for the valves may lead to problems for the pumps.

- *Only use new components that are especially adapted to fit your valve (both in terms of shape and chemical resistance).*
- *Use the correct spare parts kits. In the event of doubt, refer to the exploded views and ordering information in the appendix.*

10.1 Cleaning valves



Clean the discharge and suction valves only one after another as they cannot be differentiated using the arrow markings.

For orientation: Should you have a dismantled liquid end in front of you, the suction valve is on the side of the diaphragm rupture sensor.

Personnel: ■ Technical personnel

Cleaning a discharge valve (double ball)

Taking the discharge valve apart

1. ➤ Loosen the discharge line.
2. ➤ Unscrew the discharge valve from the dosing head and rinse out.
3. ➤ Remove the remaining parts from the dosing head.
4. ➤ Allow the parts from the valve body (1) to fall as far as possible.
5. ➤ Using an Allen key or similar, insert it through the hole of the valve body (1) and push the remaining parts out of it.
6. ➤ Remove the last seal (2) and the last ball seat (3) from the valve body (1) using a small screwdriver.
7. ➤ Rinse and clean all parts.
8. ➤ Replace the worn parts and seals.


Assembling the discharge valve



When assembling, take note of the orientation of the valve seats (3). The valve seats (3) are used as a ball seat on the fine machined side and as a ball cage and spring guide on the other side. The fine machined side must point in the flow direction with all valve seats.

When assembling the valves, take note of the sequence:

Teflon – metal – Teflon – metal - ...



1. ➤ Slide into the valve body (1) one after another:
 - one seal (2) and one valve seat (3) (direction!)
 - one seal (2) and one valve bushing (4)
 - (If fitted: allow one spring (*) to slide into the spring guide of the valve seat (3))
 - slide one ball (5) into the valve body (1)
 - one seal (2) and the second valve seat (3) (direction!)
 - one seal (2) and the second valve bushing (4)
 - (If fitted: allow the second spring (*) to slide into the spring guide of the valve seat (3))
 - slide the second ball (5) into the valve body (1)
 - one seal (2), the third valve seat (3) (direction!) and a further seal (2)

2. ➤ Position the insert disc (6) with the flare on the packing.



The distance between the edge of the valve body and the insert disk (6) is due to the construction.

3. ➤ Place the larger seal (7) between the insert disc (6) and the dosing head.
4. ➤ Screw in the valve until the stop.
5. ➤ Fix the discharge line.

Fig. 17

Cleaning a suction valve (double ball)

A suction valve is dismantled, cleaned and assembled in the same way as a discharge valve.



Please note, however, that when assembling, the valve seat (3) must be aligned in the other direction. The fine machined side must point in the direction of flow with all valve seats (3).

10.2 Replacing the diaphragm

Important note



WARNING!

Observe the safety information at the beginning of the chapter.



CAUTION!

A diaphragm rupture may remain unnoticed

Should the multi-layer diaphragm be handled incorrectly, the diaphragm rupture warning system may fail.

- Take the multi-layer diaphragm from the packaging immediately before installing it.
- Do not allow dirt to come into contact with the multi-layer diaphragm.
- Do not "inspect" the insert discs.

With the double head versions and add-on power ends, perform the following work simultaneously on both dosing heads.

Drain the hydraulic oil from the hydraulic end

Position numbers - refer to the "Maintenance" chapter

1. Turn the stroke adjustment dial (2) more than 100% to the stop.
2. Unscrew the gearbox vent stopper (3).
3. Place an oil trough under the hydraulic end.
4. Unscrew the oil drainage stopper (4) out of the hydraulic end.
5. Allow the hydraulic oil to run out of the hydraulic end.
6. Screw in the oil drainage stopper (4) with a new seal.

Changing the diaphragm for HP2 and HP3




Fig. 18

1. ➤ Depressurise the suction and discharge lines.
2. ➤ Unscrew the suction and discharge lines from the liquid end. Is the hydraulic oil drained - see above?
3. ➤ Remove the liquid end with the dosing head screws from the hydraulic end.
4. ➤ Release the diaphragm mounting plate (2) with diaphragm (1) from the dosing head.

5. ➤



WARNING!

Warning of injury to eyes

The spring (3) and the spring collar (5) on the diaphragm anchor (6) may spring away when loosening the safety collar (4).

- Wear safety glasses.

Release the safety collar (4) and the spring (3) with the spring collar (5) from the diaphragm anchor.

6. ➤ Release the safety collar (4).
7. ➤ Pull the spring (3) with the spring collar (5) from the diaphragm anchor.
8. ➤ Remove the diaphragm / diaphragm anchor combination from the diaphragm mounting plate (2).
9. ➤ Place the new diaphragm / diaphragm anchor combination into the diaphragm mounting plate (2).
10. ➤ Push the diaphragm spring (3) with the spring collar (5) on to the diaphragm anchor (6).
11. ➤ Secure the spring collar (5) using the safety collar (4).
12. ➤ Replace the O-ring (7) between the diaphragm mounting plate (2) and the hydraulic end.
13. ➤ Place the diaphragm (1) with the diaphragm mounting plate (2) inside the hydraulic end.
14. ➤ Position the dosing head with the screws so that the suction connector is pointing downwards - diaphragm rupture sensor must be at the bottom.
15. ➤ First gently tighten the dosing head screws and then tighten cross-wise, tightening torque - ⚡ 'Tightening torque for screws' on page 64.
16. ➤ Test the diaphragm rupture sensor - see ⚡ 'Changing the diaphragm for HP2 and HP3' on page 62
17. ➤ Screw the suction and discharge line onto the liquid end.











Fig. 19: Wetted areas (grey shaded)

Tightening torque for screws

Dosing head material	1st level	2nd level
PVT	6 Nm	12 Nm
TTT	6 Nm	12 Nm
HCT	8 Nm	20 Nm
SST	8 Nm	20 Nm

Fill hydraulic oil in the hydraulic end

For the double head versions, perform the following work simultaneously on both dosing heads.

1.  Set the stroke adjustment dial (1) to "100%" and open the safety relief valve (2) - tighten the knurled screw.
2.  Slowly fill hydraulic oil through the opening for the gearbox vent stopper (4) until the oil inspection window (3) is covered to 1/3.
3.  Start the pump.
4.  Allow the pump to run for 1... 2 minutes.
5.  Screw the gearbox vent stopper (3) back in. Do not close the bleed valve!
6.  Close the safety relief valve (1) - loosen the knurled screw.
7.  Check the pump for tightness by using maximum back pressure.



WARNING!

Only in areas at risk from explosion: Check after 1 day whether the oil drainage stopper (4) and the oil drainage plug (5) are still tight.



Check the starting torque of the dosing head screws again after 24-hours of operation!

10.3 Repairing the diaphragm rupture sensor



WARNING!

Feed chemical warning

After a diaphragm rupture, additional feed chemical will be present in the diaphragm rupture sensor and the feed channel in the dosing head.

- Protect yourself from the feed chemical if using hazardous or unknown feed chemicals. Observe the material safety data sheet.

30 V version

Check diaphragm rupture sensor




Fig. 20

1. ➤ When changing the diaphragm, unscrew the diaphragm rupture sensor from the dosing head.
2. ➤ Check for electrical continuity:
3. ➤ Using a blunt insulating probe ($\varnothing 2 \dots 3$ mm, no sharp edges), press into the channel of the diaphragm rupture sensor.
 - ⇒ Check that there is no electrical continuity
4. ➤ Release the pin again.
 - ⇒ Electrical continuity must be re-established.
5. ➤ Repeat the test several times.
6. ➤ If everything is working correctly, screw the diaphragm rupture sensor into the dosing head with a new seal (1).
7. ➤ If not, go to the next section.

Replace separating diaphragm of the diaphragm rupture sensor

1. ➤ Disconnect the diaphragm rupture sensor from the power supply.
2. ➤ When changing the diaphragm, unscrew the diaphragm rupture sensor from the dosing head.
3. ➤ Grasp the upper section (2) of the diaphragm rupture sensor.
4. ➤ Hold the body (5) in place with an open-ended spanner.
5. ➤ Unscrew the top of the diaphragm rupture sensor.
6. ➤ Clean the soiled parts.
7. ➤ Lay the new separating diaphragm (3) with the light side (PTFE) down into the upper section (2).
8. ➤ Lay the plate (4) with the uneven side down into the upper section (2).
9. ➤ Screw the body (5) into the upper section and screw tighten.
10. ➤ Check the diaphragm rupture sensor as described in "Check diaphragm rupture sensor".
11. ➤ If the diaphragm rupture sensor does not operate clearly and reliably, then a new diaphragm rupture sensor must be used without fail.

ATEX version

Checking the diaphragm rupture sensor




Fig. 21

1. ➤ When changing the diaphragm, unscrew the diaphragm rupture sensor from the dosing head.
2. ➤ Check that the monitor does not indicate a diaphragm rupture:
3. ➤ Using a blunt insulating probe (Ø 2 ... 3 mm, no sharp edges), press into the channel of the diaphragm rupture sensor.
 - ⇨ The monitor device should indicate a diaphragm rupture.
4. ➤ Release the pin again.
 - ⇨ The monitor device should no longer indicate a diaphragm rupture.
5. ➤ Repeat the test several times.
6. ➤ If everything is working correctly, screw the diaphragm rupture sensor into the dosing head with a new seal (1).
7. ➤ If not, go to the next section.

Replace the separating diaphragm of the diaphragm rupture sensor

1. ➤ Disconnect the diaphragm rupture sensor from the monitor.
2. ➤ When changing the diaphragm, unscrew the diaphragm rupture sensor from the dosing head.
3. ➤ Grasp the top part (2) of the diaphragm rupture sensor.

i Do not tamper with the lacquer-protected nut.

4. ➤ Hold the body (5) in place with an open-ended spanner.
5. ➤ Unscrew the top of the diaphragm rupture sensor.
6. ➤ Clean any dirty parts.
7. ➤ Lay the new separating diaphragm (3) with the light side (PTFE) down into the top part (2).
8. ➤ Place the disc (4) in the top part (2).
9. ➤ Place the spring into the body (5).
10. ➤ Move the body (5) close to the top part (2).
 - ⇨ The spring (6) should sit correctly on the spring seat (3a).
11. ➤ Screw the body (5) into the top part and tighten.
12. ➤ Connect the diaphragm rupture sensor back to the monitor.
13. ➤ Check the diaphragm rupture sensor as described under "Checking diaphragm rupture sensor".
14. ➤ If the diaphragm rupture sensor does not operate clearly and reliably, then definitively use a new diaphragm rupture sensor.

10.4 Calibrating the dosing rate

It is only worth calibrating the dosing rate if you wish to carry out particularly precise metering at a completely different back pressure.

The dosing rate of the hydraulic diaphragm metering pump is only dependent upon back pressure to a minimal extent. And the pumps are calibrated on the factory premises to the maximum operating pressure. (Value of maximum operating pressure - see the pressure stage on the indicating dial or the safety relief valve.)

The plant or production facility can calibrate each pump to a back pressure that is lower than the nominal pressure ordered.

The following pressure stages (in bar) are available:

Pump	10	16	25	40	64	100
HP2,	X	X	X	X	X	X
HP3						



WARNING!

ATEX pump only: Take suitable precautions in potentially explosive atmospheres regarding the feed chemical in the open measuring cylinder - see handling instructions below.



The dosing rate can only be calibrated when the discharge line is connected and under normal operating conditions. As the dosing rate is dependent upon the actual back pressure.




Fig. 22: a) Adjust indicating dial, b) Schematic assembly for calibration

Materials required:

- Measuring beaker
- Stop watch

1. ➤ Switch off the pump.
2. ➤ Turn the stroke adjustment dial to maximum, beyond 100% to the stop.
3. ➤ API versions only: Remove the metal cap from the stroke adjustment dial.
4. ➤ Remove the cap (4) from the stroke adjustment dial and slacken off the screw (3) beneath slightly.
5. ➤ Guide the suction line into the measuring beaker - see Fig. 22.
6. ➤ Fill the measuring beaker with feed chemical.
7. ➤ Start the pump.
8. ➤ As soon as the system back pressure of the system has been reached, determine the fill level Q_1 and start the stopwatch.
9. ➤ Run the pump for a while.
10. ➤ Simultaneously determine the fill level Q_2 and stop the stopwatch.
11. ➤ Calculate the dosing rate value.

- 12.** ▶ Reduce the dosing rate using the stroke adjustment dial and repeat steps 7 to 10 until the required value is reached.
- 13.** ▶ Turn the indicating dial (1) only until the 100% marking is precisely above the indicating slit (2).
- 14.** ▶ Carefully tighten the screw (3) in the stroke adjustment dial and replace the cap (4).
- 15.** ▶ API versions only: Press the metal cap on to the stroke adjustment dial.

10.5 Replacing power end bearings

Only allow ProMinent Service to replace the power end bearings!

11 Troubleshooting

Safety information



WARNING!

ATEX pumps in the ATEX area

- Generally ensure that the parts are working properly (no leaks, unusual noises, high temperatures, unusual smell ...) especially the power end/drive and the bearings.
- Do not allow the pump to heat up because of a lack of oil!
With lubricated metering pumps, regularly check for the presence of lubricant, for example by checking the liquid level, visual leak control etc. If oil is leaking, examine the leakage point immediately and eliminate the cause.
- When cleaning plastic components, ensure that no electrostatic charges are generated by excessive friction. - see warning label.
- Replace wear parts, such as bearings, when there is an identifiable incidence of unacceptable wear. (The nominal service life cannot be calculated with lubricated bearings.)
- Only use genuine spare parts as replacements.
- Carry out inspections and repair in compliance with DIN EN IEC 60079-17 and ensure that they are only performed by "experienced personnel with the requisite knowledge".
- Make sure that a "recognised competent person" checks the electrical installation and in particular the intrinsically safe electric circuits.



WARNING!

ATEX pumps in areas at risk from explosion

Static electricity can cause ignition sparks.

- Consider potential equalisation before you approach any pump equipment that could be at a different electrical potential (such as pipes or tools)



WARNING!

Fire hazard with flammable media

Only with flammable media: They can be ignited by oxygen.

- The pump may not work if there is a mixture of feed chemical with oxygen in the liquid end. A specialist may need to take appropriate actions (using inert gas, ...).



WARNING!

Danger of an electric shock

Personnel working on electrical parts can be electrocuted if all electrical lines carrying current have not been disconnected.

- Disconnect the supply cable before working on the motor and prevent it from being reconnected accidentally.
- Any separately driven fans, servo motors, speed controllers or diaphragm rupture sensors fitted should also be disconnected.
- Check that the supply cables are de-energised.



WARNING!

Warning of hazardous feed chemical

Should a dangerous feed chemical be used: it may escape from the hydraulic components when working on the pump, material failure or incorrect handling of the pump.

- Take appropriate protective measures before working on the pump (e.g. safety glasses, safety gloves, ...). Adhere to the material safety data sheet for the feed chemical.
- Drain and flush the liquid end before working on the pump.



WARNING!

Risk of injury from the fan impeller

The fan impeller beneath motor's fan cowling can cause severe injuries while it is turning.

- The pump must only be connected to the mains voltage with the fan cowling closed.



WARNING!

Only motors with a frequency converter: Danger of electric shock

The danger of electric shock remains for 3 minutes after the mains voltage has been switched off on conducting parts of the motor with an integrated frequency converter and on the lines themselves.

- After switching off, allow the device to stand for 3 minutes before opening the terminal box.



CAUTION!

Only motors with a frequency converter: The motor can be damaged

The input current limiter could be damaged if a motor with an integrated frequency converter is restarted within 3 minutes of the mains voltage being switched off.

- After switching off, allow the device to stand for at least 3 minutes before restarting.



CAUTION!

Danger of personnel injury and material damage

The use of untested third party parts can result in personnel injuries and material damage.

- Only fit parts to metering pumps, which have been tested and recommended by ProMinent.



CAUTION!

Warning of feed chemical spraying around

Feed chemical can spray out of the hydraulic components if they are manipulated or opened due to pressure in the liquid end and adjacent parts of the system.

- Disconnect the pump from the mains power supply and ensure that it cannot be switched on again by unauthorised persons.
- Depressurise the system before commencing any work on hydraulic parts.

Tasks

Fault description	Cause	Remedy	Personnel
Pump fails to pressurise or does not prime despite full stroke motion and bleeding.	The valves are dirty or worn.	Repair the valves - see chapter entitled "Repair".	Technical personnel
	The feed chemical has particles larger than 0.3 mm.	Install a suitable filter in the suction line.	Technical personnel
	Safety relief valve is open.	Unscrew knurled screw in safety relief valve.	Instructed personnel
	Safety relief valve is heavily worn as discharge line is greatly constricted.	Replace safety relief valve and remove blockage from discharge line	Technical personnel
	Insufficient hydraulic oil in the power end.	Refill with hydraulic oil until the oil inspection window is 1/3 covered - see "Changing the diaphragm" in the "Repair" chapter. Investigate and clear the cause of the oil loss.	Instructed personnel
	The oil inspection window is leaking.	Replace the oil inspection window as per the operating instructions.	Technical personnel
	Indicating dial is set incorrectly.	Set indicating dial - see "Calibrating capacity" in the chapter "Repair".	Technical personnel
	The motor is wired incorrectly.	1. Check the mains voltage and mains frequency. 2. Wire the motor correctly.	Electrician
	The mains voltage has failed.	Eliminate the cause.	Electrician
	Operating diaphragm ruptured and alarm has not sounded.	<ul style="list-style-type: none"> ■ Replace multi-layer diaphragm immediately - see "Diaphragm change" in the chapter "Repair". ■ Replace separating diaphragm of the diaphragm rupture sensor- see "Replacing the separating diaphragm, diaphragm rupture sensor" in the chapter "Repair". 	Technical personnel
The overpressure sensor has triggered.	There is a blockage in the discharge line.	Clear the blockage.	Technical personnel
	The system back pressure was momentarily too high.	Clear the cause of the back pressure.	Technical personnel

Troubleshooting

Fault description	Cause	Remedy	Personnel
The diaphragm rupture sensor has triggered.	The operating diaphragm has ruptured.	<ul style="list-style-type: none">■ Replace multi-layer diaphragm immediately - see "Diaphragm change" in the chapter "Repair".■ Replace separating diaphragm of the diaphragm rupture sensor- see "Replacing the separating diaphragm, diaphragm rupture sensor" in the chapter "Repair".	Technical personnel
The power end motor is very hot.	The discharge line is seriously constricted.	<ul style="list-style-type: none">■ Rectify any constriction of the discharge line.■ Have the safety relief valve checked.	Technical personnel
All other faults.	Other causes.	Call ProMinent Service.	

12 Decommissioning and disposal

12.1 Decommissioning

**WARNING!****Fire hazard with flammable media**

Only with flammable media: They can be ignited by oxygen.

- The pump may not work if there is a mixture of feed chemical with oxygen in the liquid end. A specialist may need to take appropriate actions (using inert gas, ...).

**WARNING!****Danger of an electric shock**

When working on the motor or electrical auxiliary equipment, there is a danger of an electric shock.

- Before working on the motor, take note of the safety instructions in its operating instructions!
- Should external fans, servomotors or other auxiliary equipment be installed, these should also be disconnected and checked that they are voltage free.

**WARNING!****Danger from chemical residue**

There is normally chemical residue in the liquid end and on the housing after operation. This chemical residue could be hazardous to people.

- It is mandatory that the safety information in the "Storage, transport and unpacking" chapter is read before shipping or transporting the unit.
- Thoroughly clean the liquid end and the housing of chemicals and dirt. Adhere to the material safety data sheet for the feed chemical.

**WARNING!****Warning of hazardous feed chemical**

Should a dangerous feed chemical be used: it may escape from the hydraulic components when working on the pump, material failure or incorrect handling of the pump.

- Take appropriate protective measures before working on the pump (e.g. safety glasses, safety gloves, ...). Adhere to the material safety data sheet for the feed chemical.
- Drain and flush the liquid end before working on the pump.

**WARNING!****Hot oil and hot components**

The hydraulic oil and the hydraulic end may become very hot when the pump is exposed to heavy loading.

- Allow the pump to cool before starting work.



CAUTION!

Warning of feed chemical spraying around

Feed chemical can spray out of the hydraulic components if they are manipulated or opened due to pressure in the liquid end and adjacent parts of the system.

- Disconnect the pump from the mains power supply and ensure that it cannot be switched on again by unauthorised persons.
- Depressurise the system before commencing any work on hydraulic parts.



CAUTION!

Danger of damage to the device

The device may be damaged by incorrect and improper storage and transport.

- Take into account the information in the "Storage, Transport and Unpacking" chapter if the system is decommissioned for a temporary period.

Personnel: ■ Technical personnel

1. ➤ Disconnect the pump from the mains.
2. ➤ Depressurise and bleed the hydraulic system around the pump.
3. ➤ Flush the liquid end with a suitable medium - observe the material safety data sheet! Flush the dosing head thoroughly when using hazardous feed chemicals!
4. ➤ Drain the hydraulic oil - refer to the "Maintenance" chapter.
5. ➤ Thoroughly clean the liquid end and the housing of chemicals and dirt.
6. ➤ Possible additional work - refer to the "Storage, transport and unpacking" chapter.

12.2 Disposal

Personnel: ■ Technical personnel



WARNING!

Danger due to spring tension

There is a spring under high tension between the diaphragm and the diaphragm mounting plate.

- Wear safety glasses.



WARNING!

Danger due to spring tension

There is a spring under high tension below the hydraulic cap under the diaphragm mounting plate.

- Only remove the hydraulic cap in line with the "Hydro repair and configuration instructions."



CAUTION!

Environmental hazard due to hydraulic oil

The pump contains hydraulic oil, which can cause damage to the environment.


- Drain the hydraulic oil from the pump.
- Note the local guidelines currently applicable in your country.



CAUTION!

Note the local guidelines generally currently applicable in your country.

Sign indicating EU collection system



In accordance with the European Directive 2012/19/EU on waste electrical and electronic equipment, this device features the symbol showing a waste bin with a line through it. The device must not be disposed of along with domestic waste. To return the device, use the return and collection systems available and observe the local legal requirements.

13 Technical data

Only with "M - modified" design:



WARNING!

Risk of personal injuries

Please observe the "Supplement for modified version" at the end of the chapter!

It replaces and supplements the technical data!

13.1 Performance data

HP2a with 50 Hz operation

Type	Minimum pump capacity at maximum back pressure			Maximum stroke rate	Suction lift	Permissible priming pressure, suction side	Connector size
	bar	l/h	ml/stroke				
100003*	100	3	0.8	60	3	5	SST: Rp 1/4" PVT: DN10
100006*	100	6	0.8	125	3	5	SST: Rp 1/4" PVT: DN10
100007*	100	7	0.8	150	3	5	SST: Rp 1/4" PVT: DN10
100009*	100	9	0.8	187	3	5	SST: Rp 1/4" PVT: DN10
100010*	100	10	0.8	212	3	5	SST: Rp 1/4" PVT: DN10
064007	64	7	2.0	60	3	5	G 3/4M - DN10
064015	64	15	2.0	125	3	5	G 3/4M - DN10
064018	64	18	2.0	150	3	5	G 3/4M - DN10
064022	64	22	2.0	187	3	5	G 3/4M - DN10
064025	64	25	2.0	214	3	5	G 3/4M - DN10
025019	25	19	5.3	60	3	5	G 3/4M - DN10 **
025040	25	40	5.3	125	3	5	G 3/4M - DN10 **
025048	25	48	5.3	150	3	5	G 3/4M - DN10 **
025060	25	60	5.3	187	3	5	G 3/4M - DN10 **
025068	25	68	5.3	214	3	5	G 3/4M - DN10 **

* Material version SST / HCT with double ball valve

Alternatively double ball valve SST with RP 3/8

** HV version for G1-DN 15

Maximum back pressure for liquid ends in material version PVT: 25 bar!

Maximum back pressure for liquid ends in material version TTT: 16 bar!

The metering capacity can deviate from the details above with HV versions.

All figures refer to water at 20 °C.

Priming lift / priming pressure (dry) determined for empty suction line and empty liquid end and as well as clean and moistened valves (the figures are lower with valve springs).

The suction lift / suction pressure applies to filled suction lines and filled liquid end - when installed correctly.

Technical data

HP2a with 60 Hz operation

Type	Minimum pump capacity at maximum back pressure				Maximum stroke rate	Suction lift	Permissible priming pressure, suction side	Connector size
	bar	psi	l/h	gph				
100003*	100	1,450	3.6	1.0	72	3	5	SST: Rp 1/4" PVT: DN10
100006*	100	1,450	7	1.8	150	3	5	SST: Rp 1/4" PVT: DN10
100007*	100	1,450	8	2.1	180	3	5	SST: Rp 1/4" PVT: DN10
100009*	100	1,450	11	2.9	224	3	5	SST: Rp 1/4" PVT: DN10
064007	64	928	8.4	2.2	72	3	5	G 3/4M - DN10
064015	64	928	18	4.8	150	3	5	G 3/4M - DN10
064018	64	928	21	5.5	180	3	5	G 3/4M - DN10
064022	64	928	26	6.9	224	3	5	G 3/4M - DN10
025019	25	362	23	6.1	72	3	5	G 3/4M - DN10 **
025040	25	362	48	12.7	150	3	5	G 3/4M - DN10 **
025048	25	362	58	15.3	180	3	5	G 3/4M - DN10 **
025060	25	362	72	19.0	224	3	5	G 3/4M - DN10 **

* Material version SST / HCT with double ball valve

Alternatively double ball valve SST with RP 3/8

** HV version for G1-DN 15

Maximum back pressure for liquid ends in material version PVT: 25 bar!

Maximum back pressure for liquid ends in material version TTT: 16 bar!

The metering capacity can deviate from the details above with HV versions.

All figures refer to water at 20 °C.

Priming lift / priming pressure (dry) determined for empty suction line and empty liquid end and as well as clean and moistened valves (the figures are lower with valve springs).

The suction lift / suction pressure applies to filled suction lines and filled liquid end - when installed correctly.

HP3a with 50 Hz operation

Type	Minimum pump capacity at maximum back pressure			Maximum stroke rate	Suction lift	Permissible priming pressure, suction side	Connector size
	bar	l/h	ml/stroke				
100010*	100	10	2.8	60	3	5	G 3/4M - DN10 **
100021*	100	21	2.8	125	3	5	G 3/4M - DN10 **
100025*	100	25	2.8	150	3	5	G 3/4M - DN10 **
100031*	100	31	2.8	187	3	5	G 3/4M - DN10 **
100035*	100	35	2.8	212	3	5	G 3/4M - DN10 **
064019	64	19	5.3	60	3	5	G 3/4M - DN10 **
064040	64	40	5.3	125	3	5	G 3/4M - DN10 **
064048	64	48	5.3	150	3	5	G 3/4M - DN10 **
064060	64	60	5.3	187	3	5	G 3/4M - DN10 **
064068	64	68	5.3	214	3	5	G 3/4M - DN10 **
025048	25	48	13.4	60	3	5	G 1M - DN15 ***
025100	25	100	13.4	125	3	5	G 1M - DN15 ***
025120	25	120	13.4	150	3	5	G 1M - DN15 ***
025150	25	150	13.4	187	3	5	G 1M - DN15 ***
025170	25	170	13.4	214	3	5	G 1M - DN15 ***

* Material version SST / HCT with double ball valve

Alternatively double ball valve SST with RP 3/8

** HV version for G1M - DN 15

*** HV version G 1 1/4M - DN 20

Maximum back pressure for liquid ends in material version PVT: 25 bar!

Maximum back pressure for liquid ends in material version TTT: 16 bar!

The metering capacity can deviate from the details above with HV versions.

All figures refer to water at 20 °C.

Priming lift / priming pressure (dry) determined for empty suction line and empty liquid end and as well as clean and moistened valves (the figures are lower with valve springs).

The suction lift / suction pressure applies to filled suction lines and filled liquid end - when installed correctly.

HP3a with 60 Hz operation

Type	Minimum pump capacity at maximum back pressure				Maximum stroke rate	Suction lift	Permissible priming pressure, suction side	Connector size
	bar	psi	l/h	gph				
100010*	100	1,450	12	3.2	72	3	5	G 3/4M - DN10 **
100021*	100	1,450	25	6.6	150	3	5	G 3/4M - DN10 **
100025*	100	1,450	30	7.9	180	3	5	G 3/4M - DN10 **
100031*	100	1,450	37	9.8	224	3	5	G 3/4M - DN10 **
064019	64	928	23	6.1	72	3	5	G 3/4M - DN10 **
064040	64	928	48	12.7	150	3	5	G 3/4M - DN10 **
064048	64	928	58	15.3	180	3	5	G 3/4M - DN10 **
064060	64	928	72	19.0	224	3	5	G 3/4M - DN10 **
025048	25	362	58	15.3	72	3	5	G 1" - 10 ***
025100	25	362	120	31.7	150	3	5	G 1" - 10 ***
025120	25	362	144	38.0	180	3	5	G 1" - 10 ***
025150	25	362	180	47.6	224	3	5	G 1" - 10 ***

* Material version SST / HCT with double ball valve

Alternatively double ball valve SST with RP 3/8

*** HV version G 1M - DN 15

*** HV version G 1 1/4M - DN 20

Maximum back pressure for liquid ends in material version PVT: 25 bar!

Maximum back pressure for liquid ends in material version TTT: 16 bar!

The metering capacity can deviate from the details above with HV versions.

All figures refer to water at 20 °C.

Priming lift / priming pressure (dry) determined for empty suction line and empty liquid end and as well as clean and moistened valves (the figures are lower with valve springs).

The suction lift / suction pressure applies to filled suction lines and filled liquid end - when installed correctly.

13.2 Metering reproducibility

Data	Value	Unit
Reproducibility	±1	% *

* for measurements taken under constant conditions, minimum 20 % stroke rate and water at 20 °C - when installed correctly and with a back pressure of at least 1.5 bar

13.3 Viscosity

The liquid ends are generally suitable for the following viscosity ranges:

Design	Range	Unit
no valve springs	0 ... 200	mPas
with valve springs	200 ... 500	mPas
HV (for highly viscous feed chemicals)	500 ... approx. 3000 *	mPas

* Only when the installation is correctly adjusted.

13.4 Weight

For SST material version pumps with standard motor.

Pump	Design	Weight
		kg
HP2a	Single head	31
	Double head	41
	Add-on power end	24
	Add-on power end, double head	34
HP3a	Single head	41
	Double head	55
	Add-on power end	34
	Add-on power end, double head	48

13.5 Wetted materials

Material version	Liquid end	Suction/pressure connector	Seals	Ball seat	Valve balls
SST	Stainless steel 1.4571//1.4404 / 1.4404	Stainless steel 1.4581	PTFE	ZrO ₂	Ceramic
HCT	Hastelloy C	Hastelloy C	PTFE	Hastelloy C	Ceramic
PVT	PVDF	PVDF	PTFE	PTFE	Ceramic
TTT	PTFE + carbon	PVDF	PTFE	PTFE	Ceramic

13.6 Ambient conditions

13.6.1 Temperatures

Pump, compl.

Data	Value	Unit
Storage and transport temperature	-10 ... +50	°C
Ambient temperature in operation ("Standard" version, for drive):	-10 ... +40	°C
Ambient temperature in operation ("Low temperature" version, for drive):	-25 ... +40	°C
Ambient temperature in operation ("Low temperature Zone 2" version, for drive):	-20 ... +40	°C

* Only with heating heating cartridge

PVT liquid end

Data	Value	Unit
Max. temperature, long-term at max. operating pressure	65	°C
Minimum temperature "Standard"	-10	°C
Max. temperature, for 15 min at max. 2 bar	100	°C

TTT liquid end

Data	Value	Unit
Max. temperature, long-term at max. operating pressure	50	°C

HCT - ATEX liquid end

Data	Value	Unit
Max. temperature, long-term at max. operating pressure	90	°C

HCT liquid end

Data	Value	Unit
Max. temperature, long-term at max. operating pressure	90	°C
Max. temperature, for 15 min at max. 2 bar	120	°C

SST - ATEX liquid end

Data	Value	Unit
Max. temperature, long-term at max. operating pressure	90	°C

SST liquid end

Data	Value	Unit
Max. temperature, long-term at max. operating pressure	90	°C
Max. temperature, for 15 min at max. 2 bar	120	°C

13.6.2 Air humidity

Data	Value	Unit
Maximum air humidity*:	92	% relative humidity

*non-condensing (according to DIN IEC 60068-2-30)

13.6.3 Installation height

Data	Value	Unit
Maximum installation height*:	1000	m above standard zero

* with standard pumps: Fit at higher installation heights at your own risk.

with ATEX pumps: We urgently advise that you contact a specialist for ATEX motors at higher installation heights!

13.7 Housing degree of protection

Data	Value
Protection against contact and moisture*	IP 55

*according to EN IEC 60529

13.8 Motor data

Electrical data

Tab. 8: HP2

Identity code specification	Phases, protection	Rated voltage	Mains frequency	Rated output HP2a	Remarks
S	3-phase, IP 55	220-240 V / 380-420 V	50 Hz	0.37 kW	
		250-280 V / 440-480 V	60 Hz	0.37 kW	
L1	3-phase, II 2G Ex eb IIC T3 Gb	220-240 V / 380-420 V	50 Hz	0.37 kW	
L2	3-phase, II 2G Ex de IIC T4	220-240 V / 380-420 V	50 Hz	0.37 kW	with PTC, speed control range 1:5
P1	3-phase, II 2G Ex eb IIC T3 Gb	250-280 V / 440-480 V	60 Hz	0.37 kW	
P2	3-phase, II 2G Ex de IIC T4	250-280 V / 440-480 V	60 Hz	0.37 kW	with PTC, speed control range 1:5
R/Z	3-phase, IP 55	230 V / 400 V	50/60 Hz	0.37 kW	with PTC, speed control range 1:20 with external fan 1-phase 230 V; 50/60 Hz

Technical data

Identity code specification	Phases, protection	Rated voltage	Mains frequency	Rated output HP2a	Remarks
V0	1-phase AC, IP 55	230 V \pm 10%	50/60 Hz	0.37 kW	Variable speed motor with integrated frequency converter
V2	3 phase, II 2G EX db IIC T3...T6 Gb	400 V \pm 10%	50/60 Hz	0.55 kW	EX-variable speed motor with integrated frequency converter

Tab. 9: HP3


Identity code specification	Phases, protection	Rated voltage	Mains frequency	Rated output	Remarks
S	3-phase, IP 55	220-240 V / 380-420 V	50 Hz	0.75 kW	
		250-280 V / 440-480 V	60 Hz	0.75 kW	
L1	3-phase, II 2G Ex eb IIC T3 Gb	220-240 V / 380-420 V	50 Hz	0.75 kW	
L2	3-phase, II 2G Ex de IIC T4	220-240 V / 380-420 V	50 Hz	0.75 kW	with PTC, speed control range 1:5
P1	3-phase, II 2G Ex eb IIC T3 Gb	250-280 V / 440-480 V	60 Hz	0.75 kW	
P2	3-phase, II 2G Ex de IIC T4	250-280 V / 440-480 V	60 Hz	0.75 kW	with PTC, speed control range 1:5
R/Z	3-phase, IP 55	230 V / 400 V	50/60 Hz	0.75 kW	with PTC, speed control range 1:20 with external fan 1-phase 230 V; 50/60 Hz
V0	1-phase AC, IP 55	230 V \pm 10%	50/60 Hz	0.75 kW	Variable speed motor with integrated frequency converter
V2	3-phase, II 2G EX d IIC T3...T6 Gb	400 V \pm 10%	50/60 Hz		EX-variable speed motor with integrated frequency converter



Motor data sheets, special motors, special motor flanges, external fan, temperature monitoring

- For further information for the motor with identity code specification "S", refer to the motor data sheet in the Appendix. Motor data sheets can be requested for all other motors.
- For other motors than those with identity code specification "S": Pay special attention to the operating instructions for the motors.
- Special motors or special motor flanges are available on request.

13.9 Diaphragm rupture sensor

 *Install the sensor in accordance with the chapter "Installation, electrical".*


Contact (standard)


Tab. 10: Contact loading, max.

at voltage	Maximum current
30 V DC	1 A

The contact is an opener.

The contact is an potential-free.

 – *For safety reasons we recommend connecting to a protective low voltage, e.g. in accordance with EN 60335-1 (SELV).*
 – *The cable can be poled as required.*

 *Install the sensor in accordance with the chapter "Installation, electrical". Refer to its documentation.*
Sensor name: NJ1.5-8GM-N.

)


Namur sensor (Specified for EX zones)

5–25 V DC, in accordance with Namur or DIN 19234, potential-free design.

Data	Value	Unit
Rated voltage *	8	VDC
Power consumption - active surface uncovered	> 3	mA
Power consumption - active surface covered	< 1	mA
Rated switching distance	1.5	mm

* Ri ~ 1 kΩ

Cable colour	Polarity
blue	-
brown	+

 *Install the sensor in accordance with the chapter "Installation, electrical". Refer to its documentation.*
The sensor is of type NJ1.5-8GM-N.

13.10 Safety relief valve (HP2 and HP3)

Opening pressure of the respective pressure stages:

Pressure stage*	6 bar	10 bar	16 bar	25 bar	40 bar	64 bar	100 bar
Opening pressure**	10 bar	14 bar	25 bar	36 bar	49 bar	80 bar	120 bar

* Marking on the indicating scale without valve housing

** back pressure generated by the pump when discharge side is blocked \pm 3 bar

13.11 Stroke sensor

Namur sensor (identity code characteristic "stroke sensor": 1)



Install the sensor in accordance with the chapter "Installation, electrical".

Namur sensor (Specified for EX zones)

5–25 V DC, in accordance with Namur or DIN 19234, potential-free design.

Data	Value	Unit
Rated voltage *	8	VDC
Power consumption - active surface uncovered	> 3	mA
Power consumption - active surface covered	< 1	mA
Rated switching distance	1.5	mm

* Ri ~ 1 k Ω

Cable colour	Polarity
blue	-
brown	+



Install the sensor in accordance with the chapter "Installation, electrical". Refer to its documentation.

The sensor is of type NJ1.5-8GM-N.

13.12 Heating cartridge

Technical data - see enclosed operating instructions

13.13 Protection temperature limiter (ATEX only)

Technical data - see enclosed operating instructions

13.14 Filling volumes

13.14.1 Hydraulic oil

Required amount of oil			Supplied amount of oil
Type	Single-head design	Double head version	
HP 2:	approx. 2.5 l	approx. 2.9 l	3.0 l
HP 3:	approx. 3.5 l	approx. 4.0 l	4.0 l

Use	Manufacturer	Name	Viscosity class	Order no.
Standard	Mobil	Mobilube 1 SHC *	75W - 90	1006010**

* or comparative hydraulic oil

** 1 L

Use	Manufacturer	Name	Viscosity class	Order no.
Food	Mobil	SHC Cibus *	220	1007664**

* or comparative hydraulic oil

** 1 L

13.15 Sound pressure level HP2a / Hp3a

Sound pressure level

Sound pressure level LpA < 70 dB according to EN ISO 20361

at maximum stroke length, maximum stroke rate, maximum back pressure (water)

13.16 Supplement for modified versions

(With Identcode specification "Version": "M" - "modified")

Technical data

Technical data of pumps in the modified version can deviate from those of the standard pumps. They can be queried by stating the details of the serial number.

motor

The motor data sheets for the modified version are valid. They may deviate from the standard motor data sheets.


Spare parts

With a modified version, it is absolutely necessary to specify the details of the serial number requesting and ordering the spare and replacement parts.

14 Dimensional drawings

i – Compare the dimensions on the dimension sheet and pump.
 – All dimensions are in mm.

Dimensional drawing of Hydro HP2 (HP2a H)



61_02-101_00_01-73
 P_HY_0019_SW

Fig. 23: Diagram is not strictly binding.

Liquid end	A	B	C	D	E	F	G
HM 25 SST, HCT	152	239	7	50	DN10 G3/4 M	108x42	414
HM 60 SST, HCT	165	240	0.5	51	DN10 G3/4 M	108x57	415
HM 60 SST-HV	165	243.5	0.5	57	DN15G1A	108x57	421
HM 25 PVT, TTT	152	239	7	49	DN10 G3/4 M	108x42	413
HM 60 PVT, TTT	165	240	0.5	55	DN10 G3/4 M	108x57	419
"HM 25" for types 064007, 064015, 064018, 064022, 064025, 100003, 100006, 100007, 100009, 100010							
"HM 60" for types 025019, 025040, 025048, 025060, 025068							

Tab. 11: Dimension with double ball valve

Liquid end	A	B	C	D	E	G
HM 25 SST, HCT	180	241	-7	54	DN10 Rp3/8"	418
HM 60 SST, HCT	195	242	20.5	55	DN10 Rp3/8"	419

	Standard motor	Motor, controllable	EExe motor	EExde motor	Motor with frequency converter
L	377	413	469	438	569

Dimensional drawing of Hydro HP2,
double head version (HP2a D)




Fig. 24: Diagram is not strictly binding.

Liquid end	A	B	C	D	E	F	G	H
HM 25 SST, HCT	152	239	7	50	DN10 G3/4 M	108x42	596	562
HM 60 SST, HCT	165	240	0.5	51	DN10 G3/4 M	108x57	598	564
HM 60 SST-HV	165	243.5	0.5	57	DN15G1A	108x57	610	571
HM 25 PVT, TTT	152	239	7	49	DN10 G3/4 M	108x42	594	562
HM 60 PVT, TTT	165	240	0.5	55	DN10 G3/4 M	108x57	606	564
"HM 25" for types 064007, 064015, 064018, 064022, 064025, 100003, 100006, 100007, 100009, 100010								
"HM 60" for types 025019, 025040, 025048, 025060, 025068								

Tab. 12: Dimension with double ball valve

Liquid end	A	B	C	D	E	G	H
HM 25 SST, HCT	180	241	-7	54	DN10 Rp3/8"	604	566
HM 60 SST, HCT	195	242	-20.5	55	DN10 Rp3/8"	606	568

	Standard motor	Motor, controllable	EExe motor	EExde motor	Motor with frequency converter
L	377	413	369	438	569

Dimensional drawing of Hydro HP2 with add-on power end (HP2a E + HP2a A)




Fig. 25: Diagram is not strictly binding.

Liquid end	A	B	C	D	E	F	G
HM 25 SST, HCT	152	95	59	50	DN10 G3/4 M	108x42	444
HM 60 SST, HCT	165	96	52	51	DN10 G3/4 M	108x57	445
HM 60 SST-HV	165	99	49	57	DN15G1A	108x57	451
HM 25 PVT, TTT	152	95	57	49	DN10 G3/4 M	108x42	443
HM 60 PVT, TTT	165	96	51	55	DN10 G3/4 M	108x57	449
"HM 25" for types 064007, 064015, 064018, 064022, 064025, 100003, 100006, 100007, 100009, 100010							
"HM 60" for types 025019, 025040, 025048, 025060, 025068							

Tab. 13: Dimension with double ball valve

Liquid end	A	B	C	D	E	G
HM 25 SST, HCT	180	97	37	54	DN10 Rp3/8"	448
HM 60 SST, HCT	195	98	30	55	DN10 Rp3/8"	449

	Standard motor	Motor, controllable	EExe motor	EExde motor	Motor with frequency converter
L	427	463	419	488	619

Dimensional drawing of Hydro HP2 with add-on power end, double head versions (HP2a F + HP2a B)




Fig. 26: Diagram is not strictly binding.

Liquid end	A	B	C	D	E	F	G	H
HM 25 SST, HCT	152	92	59	50	DN10 G3/4 M	108x42	596	562
HM 60 SST, HCT	165	93	52	51	DN10 G3/4 M	108x57	598	564
HM 60 SST-HV	165	97	49	57	DN15G1A	108x57	610	571
HM 25 PVT, TTT	152	92	57	49	DN10 G3/4 M	108x42	594	562
HM 60 PVT, TTT	165	93	51	55	DN10 G3/4 M	108x57	606	564

"HM 25" for types 064007, 064015, 064018, 064022, 064025, 100003, 100006, 100007, 100009, 100010

"HM 60" for types 025019, 025040, 025048, 025060, 025068

Tab. 14: Dimension with double ball valve

Liquid end	A	B	C	D	E	G	H
HM 25 SST, HCT	180	94	37	54	DN10 Rp3/8"	604	566
HM 60 SST, HCT	195	95	30	55	DN10 Rp3/8"	606	568

	Standard motor	Motor, controllable	EExe motor	EExde motor	Motor with frequency converter
L	427	463	419	488	619

Motor flange HP2a





Fig. 27: Diagram is not strictly binding.

HP2a single head version with actuator, base and connecting flanges



P_HY_0070_SW
61_02-101_00_17-73

Fig. 28: Diagram is not strictly binding.

Type	A Single-ball valve DIN	A Single ball valve ANSI	A Double-ball valve DIN	A Double-ball valve ANSI
SS 100003, 100006, 100007, 100009, 100010	-	-	316	348
SS 064007, 064015, 064018, 064022, 064025	284	316	316	348
SS 025019, 025040, 025048, 025060, 025068	296	328	339	371
HC 100003, 100006, 100007, 100009, 100010	-	312	-	-
HC 064007, 064015, 064018, 064022, 064025	-	312	-	-
HC 025019, 025040, 025048, 025060, 025068	-	324	-	-

HP2a double head version with actuator,
base and connecting flanges




Fig. 29: Diagram is not strictly binding.

Dimension A - see Table on page 94

Dimensional drawing of Hydro HP3 (HP3a
H)




Fig. 30: Diagram is not strictly binding.

Dimensional drawings

Liquid end	A	B	C	D	E	F	G
HM 60 SST, HCT	165	240	12.5	51	DN10 G3/4 M	108x57	457
HM 150 SST, HCT	191	247	-0.5	65	DN15G1A	128x76	471
HM 60 SST-HV	165	243.5	12.5	57	DN15G1A	108x57	463
HM 150 SST-HV	203	251	6.5	75	DN20G1 1/4 M	128x76	481
HM 60 PVT	165	240	12.5	57	DN10 G3/4 M	108x57	463
HM 150 PVT	191	247	-0.5	61	DN15G1A	128x76	467

"HM 60" for types 064019, 064040, 064048, 064060, 064068, 100010, 100021, 100025, 100031, 100035

"HM 150" for types 025048, 025100, 025120, 025150, 025170

Tab. 15: Dimension with double ball valve

Liquid end	A	B	C	D	E	G
HM 60 SST, HCT	206	242	-2.5	55	DN10 Rp3/8"	461

	Standard motor	Motor, controllable	EExe motor	EExde motor	Motor with frequency converter
L	455	574	459	499	626

Dimensional drawing of Hydro HP3, double head version (HP3a D)




Fig. 31: Diagram is not strictly binding.

Liquid end	A	B	C	D	E	F	G	H
HM 60 SST, HCT	165	240	12.5	51	DN10 G3/4 M	108x57	641	590
HM 150 SST, HCT	191	247	-0.5	65	DN15G1A	128x76	670	604
HM 60 SST-HV	165	243.5	12.5	57	DN15G1A	108x57	653	597

"HM 60" for types 064019, 064040, 064048, 064060, 064068, 100010, 100021, 100025, 100031, 100035

"HM 150" for types 025048, 025100, 025120, 025150, 025170

Liquid end	A	B	C	D	E	F	G	H
HM 150 SST-HV	203	251	6.5	75	DN20G1 1/4 M	128x76	690	612
HM 60 PVT, TTT	165	240	12.5	55	DN10 G3/4 M	108x57	654	590
HM 150 PVT, TTT	191	247	-0.5	61	DN15G1A	128x76	661	604

"HM 60" for types 064019, 064040, 064048, 064060, 064068, 100010, 100021, 100025, 100031, 100035

"HM 150" for types 025048, 025100, 025120, 025150, 025170

Tab. 16: Dimension with double ball valve

Liquid end	A	B	C	D	E	G	H
HM 60 SST, HCT	206	242	-2.5	55	DN10 Rp3/8"	650	594

	Standard motor	Motor, controllable	EExe motor	EExde motor	Motor with frequency converter
L	505	574	459	499	626

Dimensional drawing of Hydro HP3 with add-on power end (HP3a E + HP3a A)




Fig. 32: Diagram is not strictly binding.

Liquid end	A	B	C	D	E	F	G
HM 60 SST, HCT	165	96	64	51	DN10 G3/4 M	108x57	495
HM 150 SST, HCT	191	104	50	65	DN15G1A	128x76	506
HM 60 SST-HV	165	100	61	57	DN15G1A	108x57	501
HM 150 SST-HV	203	108	40	75	DN20G1 1/4 M	128x76	516

"HM 60" for types 064019, 064040, 064048, 064060, 064068, 100010, 100021, 100025, 100031, 100035

"HM 150" for types 025048, 025100, 025120, 025150, 025170

Dimensional drawings

Liquid end	A	B	C	D	E	F	G
HM 60 PVT, TTT	165	96	63	55	DN10 G3/4 M	108x57	499
HM 150 PVT, TTT	191	104	49	61	DN15G1A	128x76	506
"HM 60" for types 064019, 064040, 064048, 064060, 064068, 100010, 100021, 100025, 100031, 100035							
"HM 150" for types 025048, 025100, 025120, 025150, 025170							

Tab. 17: Dimension with double ball valve

Liquid end	A	B	C	D	E	G
HM 60 SST, HCT	206	98	43	55	DN10 Rp3/8"	499

	Standard motor	Motor, controllable	EExe motor	EExde motor	Motor with frequency converter
L	505	624	509	549	676

Dimensional drawing of Hydro HP3 with add-on power end, double head versions (HP3a F + HP3a B)




Fig. 33: Diagram is not strictly binding.

Liquid end	A	B	C	D	E	F	G	H
HM 60 SST, HCT	165	93	64	51	DN10 G3/4 M	108x57	641	590
HM 150 SST, HCT	191	101	50	65	DN15G1A	128x76	670	604
HM 60 SST-HV	165	97	61	57	DN15G1A	108x57	653	597
HM 150 SST-HV	203	105	40	75	DN20G1 1/4 M	128x76	690	612
HM 60 PVT, TTT	165	93	63	55	DN10 G3/4 M	108x57	650	590
HM 150 PVT, TTT	191	101	49	61	DN15G1A	128x76	661	604
"HM 60" for types 064019, 064040, 064048, 064060, 064068, 100010, 100021, 100025, 100031, 100035								
"HM 150" for types 025048, 025100, 025120, 025150, 025170								

Tab. 18: Dimension with double ball valve

Liquid end	A	B	C	D	E	G	H
HM 60 SST, HCT	195	95	43	55	DN10 Rp3/8"	650	594

	Standard motor	Motor, controllable	EExe motor	EExde motor	Motor with frequency converter
L	506	603	509	549	676

Motor flange HP3a




Fig. 34: Diagram is not strictly binding.

HP3a single head version with actuator,
base and connecting flanges




Fig. 35: Diagram is not strictly binding.

Type	A Single-ball valve DIN	A Single ball valve ANSI
SS 100010, 100021, 100025, 100031, 100035	296	327
SS 064019, 064040, 064048, 064060, 064068		
SS 025048, 025100, 025120, 025150, 025170	314	343

HP3a double head version with actuator,
base and connecting flanges





Fig. 36: Diagram is not strictly binding.

Type	A Single-ball valve DIN	A Single ball valve ANSI	A Double-ball valve DIN	A Double-ball valve ANSI
SS 100010, 100021, 100025, 100031, 100035	292	337	339	385
SS 064019, 064040, 064048, 064060, 064068	292	337	339	385
SS 025048, 025100, 025120, 025150, 025170	314	355	-	-

15 Earthing drawing

Simplex single head Hydro HP2 and HP3
with actuator and heating cartridge



P_HY_0068_SW

- 2 Motor
- 3 Safety temperature limiter of heating cartridge (optional)
- 6 Actuator (optional)

16 Diagrams for setting the metering capacity

Hydro/ 2 HP2a H









Fig. 37: Metering capacity C at medium back pressure according to the stroke length s and metering capacity C on the basis of back pressure p for different types of a series.

Hydro/ 3 HP3a H









Fig. 38: Metering capacity C at medium back pressure according to the stroke length s and metering capacity C on the basis of back pressure p for different types of a series.

17 Ordering information

17.1 Exploded view drawing




Fig. 39: Exploded view of Hydro liquid end. Numbered positions = scope of delivery of PVT spare parts kit. Technical changes reserved.

- | | | | |
|---|-----------------------------|---|---------------------------------|
| 1 | Seals (Set) | 4 | Suction connection assembly |
| 2 | Valve balls | 5 | Diaphragm |
| 3 | Pressure connector assembly | * | Reinforce plate - only with PVT |

17.2 Spare parts kits

The spare parts kit includes the replacement parts for the liquid ends.

Standard delivery for material version PVT

- 1 - Diaphragm
- 1 - Suction connection assembly.
- 1 - Pressure connector assembly
- 2 - Valve balls
- 1 - Set of seals, complete

Standard delivery for material version SST / HCT

- 1 - Diaphragm
- 2 - Valve balls
- 1 - Set of seals, complete

Ordering information

Spare parts kits Hydro/ 2

for types: 100010, 100009, 100007, 100006, 100003,
064025, 064022, 064018, 064015, 064007:

for liquid end	Material version	Order no.
FMH 25 - DN 10	PVT	1005548
	SST	1005549
	SST (for double ball valves)	1005551
	HCT	1009571
	SST (with valves, fully assembled)	1005550

for types: 025068, 025060, 025048, 025040, 025019:

for liquid end	Material version	Order no.
FMH 60 - DN 10	PVT	1005552
	SST	1005553
	SST (for double ball valves)	1005555
	HCT	1009573
	SST (with valves, fully assembled)	1005554

Spare parts kits Hydro/ 3

for types: 100035, 100031, 100025, 100021, 100010,
064068, 064060, 064048, 064040, 064019:

for liquid end	Material version	Order no.
FMH 60 - DN 10	PVT	1005552
	SST	1005553
	SST (for double ball valves)	1005555
	HCT	1009573
	SST (with valves, fully assembled)	1005554

for types: 025170, 025150, 025120, 025100, 025048:

for liquid end	Material version	Order no.
FMH 150 - DN 15	PVT	1005556
	SST	1005557
	HCT	1009575
	SST (with valves, fully assembled)	1005558

17.3 Diaphragms

PTFE metering diaphragm

for liquid end	Pump type	Order no.
FMH 25	100010, 100009, 100007, 100006, 100003 064025, 064022, 064018, 064015, 064007	1005545
FMH 60	025068, 025060, 025048, 025040, 025019	1005546

Metering diaphragm PTFE / Hastelloy C, coated

for liquid end	Pump type	Order no.
FMH 25	064025, 064022, 064018, 064015, 064007	1006481
FMH 60	025068, 025060, 025048, 025040, 025019	1006482

PTFE metering diaphragm

for liquid end	Pump type	Order no.
FMH 60	064068, 064060, 064048, 064040, 064019 100035, 100031, 100025, 100021, 100010	1005546
FMH 150	025170, 025150, 025120, 025100, 025048	1005547

Metering diaphragm PTFE / Hastelloy C, coated

for liquid end	Pump type	Order no.
FMH 60	064068, 064060, 064048, 064040, 064019 100035, 100031, 100025, 100021, 100010	1006482
FMH 150	025170, 025150, 025120, 025100, 025048	1006483

17.4 General

Hydraulic oil

The pump uses a hydraulic oil that lubricates the gear at the same time.

Use	Manufacturer	Name	Viscosity class	Order no.
Standard	Mobil	Mobilube 1 SHC *	75W - 90	1006010**

* or comparative hydraulic oil

** 1 L

Use	Manufacturer	Name	Viscosity class	Order no.
Food	Mobil	SHC Cibus *	220	1007664**

* or comparative hydraulic oil

** 1 L

Ordering information

Required amount of oil			Supplied amount of oil
Type	Single-head design	Double head version	
HP 2:	approx. 2.5 l	approx. 2.9 l	3.0 l
HP 3:	approx. 3.5 l	approx. 4.0 l	4.0 l

Seal

Spare part	Order no.
Seal for the oil drainage stopper	1004803

18 EU Declaration of Incorporation for Machines HP2

For pumps without explosion protection:

In accordance with DIRECTIVE 2006/42/EC OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL, Appendix I, BASIC HEALTH AND SAFETY REQUIREMENTS, section 1.7.4.2. C.

We,

- ProMinent GmbH
- Im Schuhmachergewann 5 - 11
- D - 69123 Heidelberg, Germany,

hereby declare that the product specified below complies with the relevant basic health and safety requirements of the Directive, on the basis of its functional concept and design and in the version distributed by us.

Any modification to the product not approved by us invalidates this declaration.

Tab. 19: Extract from the EU Declaration of Incorporation

Designation of the product:	Metering pump without motor, product range Hydro 2
Product type:	HP2a _____ § 0 _____ with characteristics § = "0" or "1" or "3" or "4"
Serial number:	see nameplate on the device
Relevant directives:	Machinery Directive (2006/42/EC) Compliance with the protection targets of the Low Voltage Directive 2014/35/EU according to Appendix I, No. 1.5.1 of the Machinery Directive 2006/42/EC
Harmonised standards applied, in particular:	EN ISO 12100:2010 EN 809:1998 + A1:2009 + AC:2010
Only start up the pump when it has been established that the machine into which the pump has been installed complies with the provisions of the Machine Directive.	
Date:	20.04.2016

You can download the Declaration of Incorporation at www.prominent.com.

19 EU Declaration of Incorporation for Machines HP3

For pumps without explosion protection:

In accordance with DIRECTIVE 2006/42/EC OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL, Appendix I, BASIC HEALTH AND SAFETY REQUIREMENTS, section 1.7.4.2. C.

We,

- ProMinent GmbH
- Im Schuhmachergewann 5 - 11
- D - 69123 Heidelberg, Germany,

hereby declare that the product specified below complies with the relevant basic health and safety requirements of the Directive, on the basis of its functional concept and design and in the version distributed by us. Technical documents were produced in line with Appendix VII Part B.

Any modification to the product not approved by us invalidates this declaration.

Tab. 20: Extract from the EU Declaration of Incorporation

Designation of the product:	Metering pump without motor, product range Hydro 3
Product type:	HP3a _____ § 0 ____ with characteristics § = "0" or "1" or "3" or "4"
Serial number:	see nameplate on the device
Relevant directives:	Machinery Directive (2006/42/EC) Compliance with the protection targets of the Low Voltage Directive 2014/35/EU according to Appendix I, No. 1.5.1 of the Machinery Directive 2006/42/EC
Harmonised standards applied, in particular:	EN ISO 12100:2010 EN 809:1998 + A1:2009 + AC:2010
Only start up the pump when it has been established that the machine into which the pump has been installed complies with the provisions of the Machine Directive.	
Date:	20.04.2016

You can download the Declaration of Incorporation at www.prominent.com.

20 EC Declaration of Conformity for HP2 Machines

For pumps without explosion protection:

In accordance with DIRECTIVE 2006/42/EC OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL, Appendix I, BASIC HEALTH AND SAFETY REQUIREMENTS, section 1.7.4.2. C.

We,

- ProMinent GmbH
- Im Schuhmachergewann 5 - 11
- D - 69123 Heidelberg, Germany,

hereby declare that the product specified below complies with the relevant basic health and safety requirements of the EC Directive on the basis of its functional concept and design and in the version marketed by us.

Any modification to the product not approved by us invalidates this declaration.

Tab. 21: Extract from the EU Declaration of Conformity

Designation of the product:	Metering pump, product ranges Hydro 2
Product type:	HP2a _____ § 0 _____ with characteristics § = "R" or "S" or "T" or "V" or "Z"
Serial number:	see nameplate on the device
Relevant directives:	EC Machinery Directive (2006/42/EC) EU EMC Directive (2014/30/EU) Compliance with the protection targets of the Low Voltage Directive 2014/35/EU according to Appendix I, No. 1.5.1 of the Machinery Directive 2006/42/EC
Harmonised standards applied, in particular:	EN ISO 12100:2010, EN 809:1998 + A1:2009 + AC:2010 EN 61000-6-2:2005, EN 61000-6-4:2007 + A1:2011 EN 60204-1:2006 + A1:2009
Date:	20.04.2016

You can download the Declaration of Conformity at www.prominent.com.

21 EC Declaration of Conformity for HP3 Machines

For pumps without explosion protection:

In accordance with DIRECTIVE 2006/42/EC OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL, Appendix I, BASIC HEALTH AND SAFETY REQUIREMENTS, section 1.7.4.2. C.

We,

- ProMinent GmbH
- Im Schuhmachergewann 5 - 11
- D - 69123 Heidelberg, Germany,

hereby declare that the product specified below complies with the relevant basic health and safety requirements of the EC Directive on the basis of its functional concept and design and in the version marketed by us.

Any modification to the product not approved by us invalidates this declaration.

Tab. 22: Extract from the EU Declaration of Conformity

Designation of the product:	Metering pump, product ranges Hydro 3
Product type:	HP3a _____ § 0 _____ with characteristics § = "R" or "S" or "T" or "V" or "Z"
Serial number:	see nameplate on the device
Relevant directives:	EC Machinery Directive (2006/42/EC) EU EMC Directive (2014/30/EU) Compliance with the protection targets of the Low Voltage Directive 2014/35/EU according to Appendix I, No. 1.5.1 of the Machinery Directive 2006/42/EC
Harmonised standards applied, in particular:	EN ISO 12100:2010 EN 809:1998 + A1:2009 + AC:2010 EN 61000-6-2:2005 EN 61000-6-4:2007 + A1:2011 EN 60204-1:2006 + A1:2009
Date:	20.04.2016

You can download the Declaration of Conformity at www.prominent.com.

22 EC Declaration of Incorporation for ATEX HP2 Machines

For pumps with explosion protection:

In accordance with DIRECTIVE 2006/42/EC OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL, Appendix I, BASIC HEALTH AND SAFETY REQUIREMENTS, section 1.7.4.2. C.

We,

- ProMinent GmbH
- Im Schuhmachergewann 5 - 11
- D - 69123 Heidelberg, Germany,

hereby declare that the product specified below complies with the relevant basic health and safety requirements of the EC Directive on the basis of its functional concept and design and in the version marketed by us. Technical documents were produced in line with Appendix VII Part B.

Any modification to the product not approved by us invalidates this declaration.

Tab. 23: Extract from the EU Declaration of Incorporation

Designation of the product:	Metering pump without motor, product range Hydro 2 Design for use in areas at risk of explosion in accordance with the ATEX Directive (2014/34/EC)
Product type:	HP2a ----- § A - 0 & with the characteristic § = "1" or "3" or "4" & = "0" or "1" or "3"
Serial number:	see nameplate on the device
Relevant directives:	EU ATEX Directive (2014/34/EU) EC Machinery Directive (2006/42/EC) EU EMC Directive (2014/30/EU) Compliance with the protection targets of the Low Voltage Directive 2014/35/EU according to Appendix I, No. 1.5.1 of the Machinery Directive 2006/42/EC
Harmonised standards applied, in particular:	EN ISO 80079-36:2016, EN ISO 80079-37:2016 EN ISO 12100:2010, EN 809:1998+A1:2009+AC:2010 EN 61000-6-2:2005, EN 61000-6-4:2007+A1:2011 EN 60204-1:2006+A1:2009
Only start up the pump when it has been established that the machine into which the pump has been installed complies with the provisions of the Machine Directive.	
EX-designation:	II 2G Ex h IIC T4 Gb X for & = "0" or "1" X: maximum medium temperature 90 °C, ambient temperature -10 ... +40 °C II 3G Ex h IIB T4 Gc X for & = "3" X: maximum medium temperature 90 °C
Assess the ignition risk when combining the pump and motor.	
Date:	16.11.2018

You can download the Declaration of Incorporation at www.prominent.com.

23 EC Declaration of Incorporation for ATEX HP3 Machines

For pumps with explosion protection:

In accordance with DIRECTIVE 2006/42/EC OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL, Appendix I, BASIC HEALTH AND SAFETY REQUIREMENTS, section 1.7.4.2. C.

We,

- ProMinent GmbH
- Im Schuhmachergewann 5 - 11
- D - 69123 Heidelberg, Germany,

hereby declare that the product specified below complies with the relevant basic health and safety requirements of the EC Directive on the basis of its functional concept and design and in the version marketed by us. Technical documents were produced in line with Appendix VII Part B.

Any modification to the product not approved by us invalidates this declaration.

Tab. 24: Extract from the EU Declaration of Incorporation

Designation of the product:	Metering pump without motor, product range Hydro 3 Design for use in areas at risk of explosion in accordance with the ATEX Directive (2014/34/EC)
Product type:	HP3a ----- § A - 0 & with the characteristic § = "1" or "3" or "4" & = "0" or "1" or "3"
Serial number:	see nameplate on the device
Relevant directives:	EU ATEX Directive (2014/34/EU) EC Machinery Directive (2006/42/EC) EU EMC Directive (2014/30/EU) Compliance with the protection targets of the Low Voltage Directive 2014/35/EU according to Appendix I, No. 1.5.1 of the Machinery Directive 2006/42/EC
Harmonised standards applied, in particular:	EN ISO 80079-36:2016, EN ISO 80079-37:2016 EN ISO 12100:2010, EN 809:1998+A1:2009+AC:2010 EN 61000-6-2:2005, EN 61000-6-4:2007+A1:2011 EN 60204-1:2006+A1:2009
Only start up the pump when it has been established that the machine into which the pump has been installed complies with the provisions of the Machine Directive.	
EX-designation:	II 2G Ex h IIC T4 Gb X for & = "0" or "1" X: maximum medium temperature 90 °C, ambient temperature -10 ... +40 °C II 3G Ex h IIB T4 Gc X for & = "3" X: maximum medium temperature 90 °C
Assess the ignition risk when combining the pump and motor.	
Date:	16.11.2018

You can download the Declaration of Incorporation at www.prominent.com.

24 EC Declaration of Conformity for ATEX HP2 Machines

For pumps with explosion protection:

In accordance with DIRECTIVE 2006/42/EC OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL, Appendix I, BASIC HEALTH AND SAFETY REQUIREMENTS, section 1.7.4.2. C.

We,

- ProMinent GmbH
- Im Schuhmachergewann 5 - 11
- D - 69123 Heidelberg, Germany,

hereby declare that the product specified below complies with the relevant basic health and safety requirements of the EC Directive on the basis of its functional concept and design and in the version marketed by us.

Any modification to the product not approved by us invalidates this declaration.

Tab. 25: Extract from the EU Declaration of Conformity

Designation of the product:	Metering pump, product range Hydro 2 Design for use in areas at risk of explosion in accordance with the ATEX Directive (2014/34/EC)
Product type:	HP2a ----- § \$ - 0 & with characteristics § = "L" or "P" and \$ = "1" or "2" or § = "V" and \$ = "2" & = "0" or "1" or "3"
Serial number:	see nameplate on the device
Relevant directives:	EU ATEX Directive (2014/34/EU) EC Machinery Directive (2006/42/EC) EU EMC Directive (2014/30/EU) Compliance with the protection targets of the Low Voltage Directive (2014/35/EU) in accordance with Appendix I, No. 1.5.1 of the Machinery Directive 2006/42/EC.
Harmonised standards applied, in particular:	EN ISO 80079-36:2016, EN ISO 80079-37:2016 EN ISO 12100:2010, EN 809:1998+A1:2009+AC:2010 EN 61000-6-2:2005, EN 61000-6-4:2007+A1:2011 EN 60204-1:2006+A1:2009
EX specification of the entire system:	II 2G Ex h IIC T3 Gb X for § = "1" and & = "0" or "1" II 2G Ex h IIC T4 Gb X for § = "2" and & = "0" or "1" X: maximum medium temperature 90 °C, ambient temperature -10 ... +40 °C II 3G Ex h IIB T3 Gc X for § = "1" and & = "3" II 3G Ex h IIB T4 Gc X for § = "2" and & = "3" X: maximum medium temperature 90 °C
Date:	16.11.2018

Download the Declaration of Conformity at www.prominent.com.

25 EC Declaration of Conformity for ATEX HP3 Machines

For pumps with explosion protection:

In accordance with DIRECTIVE 2006/42/EC OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL, Appendix I, BASIC HEALTH AND SAFETY REQUIREMENTS, section 1.7.4.2. C.

We,

- ProMinent GmbH
- Im Schuhmachergewann 5 - 11
- D - 69123 Heidelberg, Germany,

hereby declare that the product specified below complies with the relevant basic health and safety requirements of the EC Directive on the basis of its functional concept and design and in the version marketed by us.

Any modification to the product not approved by us invalidates this declaration.

Tab. 26: Extract from the EU Declaration of Conformity

Designation of the product:	Metering pump, product range Hydro 3 Design for use in areas at risk of explosion in accordance with the ATEX Directive (2014/34/EC)
Product type:	HP3a - - - - - § \$ - 0 & with characteristics § = "L" or "P" and \$ = "1" or "2" or § = "V" and \$ = "2" & = "0" or "1" or "3"
Serial number:	see nameplate on the device
Relevant directives:	EU ATEX Directive (2014/34/EU) EC Machinery Directive (2006/42/EC) EU EMC Directive (2014/30/EU) Compliance with the protection targets of the Low Voltage Directive (2014/35/EU) in accordance with Appendix I, No. 1.5.1 of the Machinery Directive 2006/42/EC.
Harmonised standards applied, in particular:	EN ISO 80079-36:2016, EN ISO 80079-37:2016 EN ISO 12100:2010, EN 809:1998+A1:2009+AC:2010 EN 61000-6-2:2005, EN 61000-6-4:2007+A1:2011 EN 60204-1:2006+A1:2009
EX specification of the entire system:	II 2G Ex h IIC T3 Gb X for § = "1" and & = "0" or "1" II 2G Ex h IIC T4 Gb X for § = "2" and & = "0" or "1" X: maximum medium temperature 90 °C, ambient temperature -10 ... +40 °C II 3G Ex h IIB T3 Gc X for § = "1" and & = "3" II 3G Ex h IIB T4 Gc X for § = "2" and & = "3" X: maximum medium temperature 90 °C
Date:	16.11.2018

Download the Declaration of Conformity at www.prominent.com.



ProMinent GmbH

Im Schuhmachergewann 5-11

69123 Heidelberg, Germany

Germany

Telephone: ++49 6221 842-0

Fax: ++49 6221 842-419

Email: info@prominent.com

Internet: www.prominent.com

984721, 9, en_GB